


Assembly Manual





Dual Motor Power Recliner with Heat and Massage



CAUTION


THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Count parts before assembling.

A  1pc	B  1pc	C  1pc
Backrest	Seat	Power Supply (Output: 29V / 2A)
D  1pc		
Power Supply for Light (Output: 12V / 1A)		


Step 1

Cut the plastic ties to remove the hardware pack (Includes: Power Supply (C) and Power Supply (D)).




Step 2

Zip up the Backrest (A) and the Seat (B) together.




Step 3

Slide the Backrest (A) into the metallic quick connectors of the Seat (B). Push down the Backrest (A) firmly until each side is locked into place and an audible “click” is heard.




Step 4

Connect all the wires by matching the colors (white to white, red to red, and black to black) at the back of the Seat (B).




Step 5

Attach the back cover to the bottom of the Seat (B) with Velcro.




Step 6

Plug the Power Supply (C) and the Power Supply (D) into the power outlet. After the chair is powered on, you can enjoy by adjusting it with the Hand Controller.




Take the Hand Control out of the storage box.

LED Strip Switch



Hand Controller User Manual



Button Operation Instructions

1. : Press and hold the "On / Off" button for 2 seconds.

Press once to turn it on. It will be in low-grade heating mode, and the icon will flash slowly.
 Press once more, and it will be in medium-grade heating mode, with the icon flashing more quickly.
 Press once more, and it will be in high-grade heating mode, and the icon will flash rapidly.
 Continue to press, and the heating function will be turned off.

2. PAUSE: Pause or resume the massage.

With the heating and vibration massage functions activated, press this button once to pause both heating and vibration massage operations, and the countdown timer will also pause. Press it again to resume all functions.

Instructions

(1) During pause mode: Press the [HEAT] button first. The heating function will keep running, the vibrator will remain paused, and the countdown timer will start. When the timer expires, both the vibrator and heating function will turn off automatically.

(2) During pause mode: Press the [PAUSE] button first. Both the heating function and vibrator will keep running, and the countdown timer will start. When the timer expires, both the vibrator and heating function will turn off automatically.

3. : Long-press to lower the backrest.

4. : Long-press to raise the backrest.

5. : Long-press to raise the headrest.

6. : Long-press to lower the headrest.


7. **INTENSITY**: Massage intensity with 3 levels: Low / Medium / High.
 Default to Low when powered on.

8. **MODE**: 6 kinds of massage modes for switching.

9. **HEAT**: 3 heating levels selectable: press once for Low, press again for Medium, press a third time for High, and press a fourth time to turn off heating.

10. **TIMER**: Massage Time Setting: Maximum setting is 60 minutes; 15 minutes is the default upon power-on.

Instructions for Screen Display Area



Common Troubleshooting

Fault	Possible Causes and Solutions
No power	1. Power not connected. 2. Power cord disconnected or plug not properly inserted. 3. Connected outlet is faulty.
Light strip not lit.	1. Check if the light strip power is connected. 2. Check if the light strip connector at the bottom link is loose.