


ASSEMBLY INSTRUCTION
SKU CODE: (H10025)





SAFETY WARNINGS



1. This bed is designed for use only mattress (es) meeting the following specifications on the upper bunk.

Upper bed			
Bed Type	Length	Width	Thickness
Twin Standard	74"-75"	38 1/2"	6" max

2. Replacement parts, including additional guardrails, maybe obtained from any of our (MINH HANH IMPORT-EXPORT COMPANY LIMITED) dealers.
3. Follow the information on the warnings appearing on the upper bunk bed end structure and on the carton. Do not remove warning label from bed
4. Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.
5. Surface of mattress must be at least 5" (127mm) below the upper edge of guardrails
6. Do not allow children under 6 years of age to use the upper bunk.
7. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
8. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
9. Always use the ladder for entering and leaving the upper bunk.
10. Do not use substitute part. Contact the manufacture or dealer for replacement part
11. Use of a night light may provide added safety precaution for a child using the upper bunk..
12. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
13. The use of water or sleep flotation mattresses is prohibited
14. STRANGULATION HAZARD - Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hook, belts and jump ropes
15. Keep these instruction for future reference
16. Prohibit more than one person on upper bunk
17. We recommend assembling your bunk bed on the shipping carton to protect your floor or carpet
18. Be certain all staples are out of the box before beginning assembly on the shipping carton.




SAFETY WARNINGS
















1. At the beginning :
Tighten all hardware.
Check metal parts for rust. If found, sand and repaint using a non-lead-based paint meeting the requirements of 16 CFR 1303.
Check all wood members for deterioration and splinters. Sand down splinters and replace deteriorating wood members.
Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.
2. Twice a month
Tighten all hardware.
Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.
3. Owners shall be responsible for maintaining the legibility of the warning labels.
4. Disposal Instructions-
There shall be instructions advising the owner to disassemble and dispose of the playground equipment in such a way that no unreasonable hazards will exist at the time the playground equipment is discarded.
5. The instructions shall also include the information found in Section 4 of the United States Consumer Product Safety Commission's (USCPSC) Outdoor Home Playground Safety Handbook or specific guidelines for the product consistent with the USCPSC Handbook. A copy of this section may be found in Appendix X2.
6. Observing the following statements and warnings reduces the likelihood of serious or fatal injury.
7. Specifying the number and weight of occupants that may safely use the equipment singly or simultaneously.
8. Recommending on-site adult supervision for children of all ages,
9. Warning the owner to instruct children not to use the equipment in a manner other than intended,
10. Warning the owner to instruct children not to get equipment while it is in motion,
11. Warning the owner not to allow children to wear inappropriate items, such as but not limited to, loose fitting clothing, hood and neck drawstrings, scarves, cord-connected items, capes and ponchos. These items can cause death by strangulation.
12. Warning the owner to instruct children not to climb when the equipment is wet.
13. Warning the owner to instruct children not to attach items to the playground equipment that are not specifically designed for use with the equipment, such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard
14. Warning the owner to instruct children to remove their bike or other sports helmet before playing on the playground equipment.
15. Warning the owner to dress children with well-fitting and full foot enclosing footwear. Examples of inappropriate footwear are clogs, flip flops, and sandals.
16. Place the equipment on level ground, not less than 6 ft (1.8 m) from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires
17. Do not install home playground equipment over concrete, asphalt, packed earth, grass, carpet, or any other hard surface. A fall onto a hard surface can result in serious injury or death to the equipment user.
18. To prevent serious injury, cautionary statements shall be included which warn that children must not use the equipment until properly installed.







ASSEMBLY INSTRUCTION










Part List (Box 1-MH10025)

A7  WoodBar-1pc	A9  Side Rail-1pc	B1  WoodBar-1pc
B3  WoodBar-3pcs	B4  WoodBar-2pcs	B6  WoodBar-1pc
B8  WoodBar-1pc	B9  Panel-1pc	C3  Panel-1pc
C4  Side Rail-1pc	D4  WoodBar-5spc	D5  Slats-8pcs
D7  WoodBar-1pc		

Part List &Hardware List (Box 2-MH10025)


A1 Panel-1pc 	A3 Panel-1pc 	A5 Panel-1pc 
A6 Panel-1pc 	A8 Panel-1pc 	B2 Panel-1pc 
B5 Panel-2pcs 	B7 Panel-1pc 	D2 WoodBar-1pc 
D3 WoodBar-1pc 	14 LED lights-1pc 	15 Power outlet-1pc 

Part List (Box 3-MH10025)

A2 Panel-1pc 	A4 Panel-1pc 	C7 Panel-1pc 
C8 Panel-1pc 	C9 Panel-2pcs 	D1 Panel-2pcs 
D5 Slats-6pcs 	C2 WoodBar-2pcs 	C5 WoodBar-2pcs 
C6 WoodBar-2pcs 	C1 WoodBar-1pc 	

Hardware List (Box 2-MH10025)

1




Bolts Ø1/4" x60 mm - 20pcs

2




Wood Screws M3.5 x 12mm - 20pcs

3




Wood dowel Ø10 x 40 mm - 42pcs

4



Wood dowel Ø8 x 30 mm - 24pcs

5



Bracket-10pc

6



Wood Screws M4 x15mm-48pcs

7



Barrel Ø1/4" x 15 mm - 20pcs

8



Crescent Washer 12pcs

9




Wood Screws M4 x 30mm - 54pcs

10




Screws 1/4" x 40mm -16pcs

11




Wood dowel Ø6 x 30 mm - 9pcs

12




Bracket 42x15x15 -10pcs

13



Bracket -2pcs

16



Bolts Ø1/4" x50 mm - 12pcs

17




Screws 1/4" x 30mm -5pcs

18




M5 x 75mm -2pcs

19




M8x 80mm -2pcs

20




Allen Key - 1pc




Assembly Tools Required (Not Included)


Step 1:




Step 2:






Step 3:




Step 4:




Step 5:


16	3	8
		
8(pcs)	16(pcs)	8(pcs)




Step 6:




Step 7:




Step 8:




Step 9:




Step 10:




Step 11:




Step 12:




Step 13:





Step 14:




Step 15:





Step 16:Finish

2		15	
2(pcs)		1(pc)	
		14	
		1(pc)	



LED lights



Power outlet