

Solar Lantern Light User Manual

Model: SZ-23008A

Specification


Product name: solar lantern light
Solar panel: 2V/0.44W
Battery: NI-MH battery AA 1000mAh
Charging time: 8 - 10h (please charge the bulb in a sunny place)
Working time: 10 - 12 hours
Material: Iron wire + ABS + PP + PET
Waterproof class: IP65

Package Included

1* Lampshade
1* Solar panels

Structure

A: Hook
B: Solar Panel
C: ON/OFF Button(White toggle switch)
D: ABS PP PET material



Note

- 1: Please make sure you turn on the light before charging.
- 2: Charge the solar lantern light under direct sunshine at least 8 hours before using it for the first time.
- 3: In cloudy weather or winter, charging time may be longer and working time may be shorter, which is normal for solar lamps and should not be considered as quality problem.
- 4: If there is water inside of the lamp shade after raining, please don't worry, it is a normal phenomenon. Simply place it in direct sunlight, then it will disappear.
- 5: This light will turn on in dark environment. Please keep it away from other light source or eliminate the other light sources around the location.

Operation

- 1: Toggle "ON/OFF" to turn on the light, the switch is located on the back of the solar panel.
- 2: Install the light in an area where it can get direct sunlight.
- 3: The lamp will automatically turn on at night.

After Sales-Services Guaranteed

30 Day Warranty is guaranteed from the date of purchase. If you have any problems with your product, please contact us through your Wayfair account: Log in to Wayfair.com
Go to "My Orders" and locate this order
Click "Get Help with Order" or "Contact Seller" to submit a support ticket
To help us resolve your issue faster, please include your Order ID and attach photos showing the problem.
Our team will respond within 24– 48 hours via Wayfair's official messaging system.

Warranty

- 1) During the warranty services, we provide whether new replacement or refund for the failure to customers who use the products in accordance with the user manual.
- 2) This warranty does not cover:
 - A.Failure or damage due to improper use, repair or remodeling
 - B.Failure or damage because of falling
 - C.Failure or damage caused by fire, earthquake, flood, lightning or other natural disasters
 - D.Failure or damage when used other than its intended use
 - E.Failure or damage caused by the third-party products other than this product