


ITEM NO. DKHD1956

Scan for manual,
video & advice.

If you have any questions or concerns,
don't hesitate to reach out to us.

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)
Email: customerservice@hulalahome.com

MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.
Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.


NOTE :
This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
200 LBS



Installation:
30 minutes.



Two Person



Before You Start

Please follow the steps below:

- Unbox the package and check if all parts and accessories are complete.
- If you find something missing, stop assembly and contact your supplier immediately.
- Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.
- NOTE:Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.

Warranty

We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having dificulty with assembly? Missing parts? Please send email with your order number to **customerservice@hulalahome.com**


For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis,or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.


Exploded Diagram

Please confirm that you have received all the parts in the box and start the installation.




Parts List

A ×1




Cabinet body

B ×1




Left tripod

C ×1




Right tripod

D ×1




Left front drawstring

E ×1



Right front pull bar


F ×1



Back pull bar


Hardware List

1 ×4




Anti-tip component

2 ×4+1




Self-tapping screw
D4x20mm

3 ×2




Hardware pack

4 ×4




Expansion pipe
L30mm

5 ×4+1




Self-tapping screw
D4x40mm

6 ×1




Screwdriver

7 ×1




Hexagonal socket wrench
M5

8 ×12+1



Screw rod
M8x40mm

9 ×8+1





Wooden dowel
Ø8x30mm

ASSEMBLY INSTRUCTIONS

Step 01


1. Insert the wooden dowel (9) into the corresponding holes of the left tripod (B) and the left front pull rod (D), and insert the wooden dowel (9) into the corresponding holes of the right tripod (C) and the right front pull rod (E).
2. Pass the screw (8) through the left front pull rod (D) and the left tripod (B) to assemble them, and use the hex socket wrench (7) to lock it. Pass the screw (8) through the right front pull rod (E) and the right tripod (C) to assemble them, and use the hex socket wrench (7) to lock it.


7	 x 1	M5	8	 x 2	M8x40mm
9	 x2	Ø8x30mm			



Step 02


1. Insert the wooden dowel (9) into the corresponding holes of the left tripod (B), the right tripod (C) and the rear pull bar (F).
2. Thread the screw (8) through the rear pull bar (F) and the left tripod (B), the right tripod (C), and assemble them. Lock them with an internal hex socket wrench (7).


7	 x 1	M5	8	 x 2	M8x40mm
9	 x2	Ø8x30mm			




Step 03

1. Insert the wooden dowels (9) into the corresponding holes of the left bracket (B), the right bracket (C) and the cabinet body (A).
2. Pass the screws (8) through the left front pull bar (D), the right front pull bar (E), the left bracket (B), the right bracket (C) and the cabinet body (A) to assemble them, and then lock them with an internal hex key wrench (7).

7	 x 1	M5	8	 x 8	M8x40mm
9	 x4	Ø8x30mm			



Step 04




Note:
Before the next step, adjust the feet of the locker to keep it level.

Step 05



Pass screw (2) through the anti-fall part (1) and insert it behind the panel, then tighten with screwdriver(6).


2	x 4	D4x20mm	6	x 1	Screwdriver
1	x 2	Anti-tip component			




Step 06


Install Anti-tip device (1) to the wall in this step.

5	 x 4	D4x40mm	6	 x 1	Screwdriver
1	 x 2	Anti-tip component	4	 x 4	L30mm






1.Drill a hole in the wall with an electric drill.



2.Tap the plastic wall anchor into the hole with a hammer.



3.Secure the Anti-tip device 1 to the wall with screws 5.

Step 07

⚠WARNING




Children have died from furniture tipover.To reduce the risk of furniture tipover:

-ALWAYS install anti-tip device provided.
-NEVER exceed the maximum size an weight of the TV shown in the instructions.
-NEVER allow children to stand, climb o hang on any drawers, doors, or shelves.
-NEVER open more than one drawe at a time.
-Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!

3	x 2	Hardware pack



WWW.HULALAHOME.COM
Email: customerservice@hulalahome.com
Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)