WARNING!!

Furniture Tipping Risk. Serious risk of severe or fatal crush injuries can occur from furniture tipping over if not secured.


Children like to climb on furniture and Unsecured furniture can pose a serious danger.

Please follow all instructions and install the tip-over restraints provided.

In addition to installing the restraints, to help prevent tip-over: 1. Unless specifically designed to accommodate, do not set TV's or other heavy objects on top of this product.


2. Never allow children to climb or hang on top glass.

3. Do not step on the Table base.




D	0	Right Side Panel	1
E	\$° °	Center Panel	1
F		Door Panel	1
G		Back Panel	1
н		Side Glass Rack	2
I		Middle Glass Rack	1
J		Handle	1
к		Leg	4
L		Middle Leg	1


Hardware				
Label	Picture	Description	QTY	
1	H	Cam Lock	13	
2		Cam Bolt	13	
3		Cam Cap	13	
4		Positioning Dowel (8*30mm)	13	
5		Screw (3.5*16mm)	29	
6		Screw (4*25mm)	3	
Ø		Screw (4*38mm)	7	
8		Connector	2	
9		Allen Key	1	
10		Screwdriver (not provided)	1	
(11)		Hammer (not provided)	1	
(12)		Power Drill (not provided)	1	
Cabinet Restraint Device Hardware				
(13)		Metal Bracket	4	




Assembly Steps





This Wine Cabinet has multiple parts and may require up to 60 minutes to assemble. To give you an overview of the Wine Cabinet parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.





Unpack and place all parts on a clean, non-marring surface. Attach Cam Bolts(②) to mounting positions on top surface of Storage Box(A) with Screwdriver(⑩).












12.1) Attach Connectors((2)) to Left Side Panel(C) using Screws((5)) with Screwdriver((10)).

Tighten the Screws fully in a sequential manner.

12.2) Rotate first screw on Connectors((2)) to adjust left-right position of Door Panel(F) when necessary.

12.3) Rotate second screw on Connectors((8)) to adjust in-out position of Door Panel(F) when necessary.


Note: There are pre-existing mounting positions on the Left Side Panel to attach the Connectors.




Usage For Cabinet Restraint Device:

To Secure Wine Cabinet against wall, attach Metal Brackets((13)) to wall and product, and use Cabinet Restraint Straps((17)) to connect the Metal Brackets((13)).

Instructions:



13.1) Turn the Wine Cabinet so the back side faces you.
13.2) Attach Metal Brackets(13) to Left Side Panel(C) and Right Side Panel(D) using Pan Head Screws(16) with Screwdriver(10).



14.1) Drill two holes on wall at same height as Metal Brackets((13)) on Wine Cabinet with Power Drill((12)).


You can mark these points in two ways as below:

1) Move the Wine Cabinet back to the wall. Mark two points same height as Wine Cabinet on the wall.


Note: The Metal Brackets need to be secured to solid, load bearing surface. Please use a Stud Finder(not supplied) if needed to locate the Wall Frame.

2) Measure the height of the Metal Brackets(13) with ruler/measuring tape and mark on wall to keep them accurate and same height.

14.2) Insert Wall Plugs((14)) into holes on wall with Hammer((11)).



with Screwdriver(10).



Care & Maintenance

0010 0111	antonanoo
0 💾 🛛	Do not put hot items directly on furniture surface
	Do not clean furniture with harsh cleansers or polish.
0 Ö. •	Do not place furniture under direct sunlight.
•	Do not place furniture near heating or cooling vents.
o L.	Do not write on furniture without a padded barrier to protect the surface.
⊘	Do not place furniture outside . For indoor use only .
	Not for commercial use. For residential use only .
	Stains may be removed with mild soap solution and damp cloth.
𝑘	Children should not climb or jump on the furniture.

✓ ✓ ● Dust and pick-up spills using a clean, non-colored, lint-free cloth .

What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and furniture.

Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning. **Should I worry?**

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

