


ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515262

Dining Stool



ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515262

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the stool is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the stool legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515262




ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515262


Part List

Ⓐ




CUSHION SEAT (2 pcs)

Ⓑ




LEG LEFT (4 pcs)

Ⓒ




LEG RIGHT (4 pcs)

Ⓓ



SHORT STRETCHER (4 pcs)

Ⓔ




LONG STRETCHER (4 pcs)

ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515262

Hardware List


①



Ø 1/4" x 55 mm

BOLT (16 pcs)


②



Ø5/16" x 13 mm

LOCK WASHER (16 pcs)

③



Ø5/16"x19x2 mm

FLAT WASHER (16 pcs)


④



4 mm

ALLEN KEY (1 pc)


⑤



Ø4 x 38 mm

WOOD SCREWS (16 pcs)

Tools Requires



NOT INCLUDED


ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515262


STEP 1:

Note

Step 1: Do not tighten the bolts; wait until the frame is assembled before tightening them.



STEP 2:



ASSEMBLY INSTRUCTIONS

ITEM NO.N711P515262

COMPLETE

