

# Reesa Dining Table Setup Instructions

1. Remove the base from the carton, and turn over so the packing crate is upwards.
2. Unscrew the packing crate from the base.
3. Screw in the six black levelers included in the hardware pack.
4. Turn the base upright.
5. Place a clear scratch guard disc on each corner, and one on either side of the middle section.
6. Unpack and place the glass on to the base.