



BENCH




ASSEMBLY INSTRUCTIONS

BOX PARTS

- A. Bench Top 1 pcs
B. Legs 4 pcs



HARDWARE PACKED IN BOX

H1	ALLEN BOLT Ø8 x 50 mm	8 pcs	H2	WASHERS Ø8 x Ø20	8 pcs	H3	ALLEN KEY 6	1 pcs
								

Step 1: Clean your bench top area. Put a clean blanket on the bench top area to avoid putting scratches on your bench top.

Step 2: Put bench top (A) upside down on your clean bench top area.

Step 3: Follow the illustration to attach the legs (B) to the bench top (A) by using the bolts (H1) and washers (H2). An allen key (H3) is provided for easy assembly. Attach each leg securely one at a time.

Step 4: After all four legs are securely bolted, have two people carefully flip the bench over onto it's legs.

