

## **Assembly Instructions**



Please visit our website for the most current instructions, assembly tips, report damage, or request parts.


## General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The main type of hardware used to assemble this product is: bolts.
- V. Power tools should not be used to assemble this product.



VI. Drill may be needed for securing product to wall.

# Parts List




#### Hardware List


Α		Ø1/4"x25mm	Bolt	32	pcs
В	<=====================================	Ø4x20mm	Screw	24	pcs
С		Ø1/4"x12mm	Adjustable foot	4	pcs
D		4mm	Hex Key	1	pcs
E			Anchor	2	pcs
F		Ø4x45mm	Screw	2	pcs
G		Ø16*6.5*1.0mm	Washer	2	pcs





Philips head screwdriver required for assembly (not included)

The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.











# Step 5






- 1. Place unit in desired location and mark the wall for anchor location, drill hole using 6mm size bit.
- 2. Insert anchor (E) into wall at desired location.
- 3. Secure furniture to wall using washer (G) and screw (F) per diagram.

<sup>\*</sup> Wall anchor included for drywall mounting. Use correct anchor and hardware for your wall material.

# Step 6



Final Assembly