




ASSEMBLY INSTRUCTIONS

- 1.FASTEN TUBE (B) ONTO LAMP BASE (A)
- 2.PLACE THE SOCKET ASSEMBLY (C) ONTO THE TUBE (B)
- 3.PUT THE SHADE (E) ONTO THE SOCKET (D)
- 4.TIGHTEN SCREW COLLAR RING (F)

CLEANING

DO NOT USE POLISHER OR CLEANERS ON YOUR LAMP. JUST WIPE CLEAN WITH SOFT CLOTH.

WARNING

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER). AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS PLUG WILL FIT IN A POLARIZED OUTLET ONE WAY ONLY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG, IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED.

- 1.BIEN FIXER LA TUBE (B) SUR LA BASE DE LA LAMPE(A)
- 2.PLACER LA DOUILLE(C) SUR LA TUBE (B)
- 3.PLACER LA VERRE (E) SUR LA DOUILLE (D)
- 4.BIEN SERRER LA BAGUE VISSANTE (F)

NETTOYAGE

NE PAS UTILISER DE POLI OU DE DETERGENT SUR VOTRE LAMPE. ESSUYER SEULEMENT AVEC UN LINGE DOUX ET PROPRE.

AVERTISSEMENT

CETTE LAMPE DE TABLE UTILISE UN CORDON ELECTRIQUE AVEC EMBOUT POLARISE(I.E. UNE BRANCHE EST PLUS LONGUE QUE L'AUTRE). AFIN DE REDUIRE LES RISQUES DE CHOC ELECTRIQUE, CE CORDON S'EMBOITE SEULEMENT DANS UNE PRISE DE COURANT POLARISEE. SI L'EMBOUT N'ENTRE PAS PARFAITEMENT DANS LA PRISE, RENSER L'EMBOUT. SI L'EMBOUT N'ENTRE TOUJOURS PAS PARFAITEMENT DANS LA PRISE, CONTACTER UN ELECTRICIEN QUALIFIE. NE PAS UTILISER UNE RALLONGE ELECTRIQUE A MOINS QUE LE CORDON S'INSERE PARFAITEMENT DANS LA PRISE.