




BOOKCASE



We are here to help! Before you return it - contact us.

We do our best to insure that your furniture arrives in excellent condition.

If you need assistance with assembly or replacement parts, please call Customer Service, prior to returning the item to the store.



A x 24
(Ø1/4"x12mm)



B x 20
(Ø4.5x28mm)



C x 02
(Ø4x50mm)




D x 02




E x 02



F x 02






supplied
fourni
suministrado





not supplied
non fourni
no suministrado


1.





A		20
---	---	----

2.





A		04
---	---	----



3.





B		20
---	---	----

4.



C		02
D		02
F		02

5.
PLEASE NOTE: For your safety, to prevent the danger of this unit tipping over, it is important that the wall anchors are properly attached.



E		02
---	--	----

MADE IN CHINA
FABRIQUÉ EN CHINE
HECHO EN CHINA