


ASSEMBLY INSTRUCTIONS



+ Do Not Use Power Tools



+ Suggested Adults



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

- | | |
|--------|-------------------------|
| part # | - Corner base |
| part # | - Corner cushion |
| part # | - Armless chair base |
| part # | - Armless chair cushion |
| part # | - Chrome leg |
| part # | - Gold leg |

Do not assemble if any of the following Hardware parts are missing:


- | | |
|--------|-----------------------|
| part # | - Allen wrench |
| part # | - Bolt M8"*35mm |
| part # | - Washer M8*16mm |
| part # | - Connect metal plate |

2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Parts Included


- ① Corner base
1pc




- ② Corner cushion
1pc




- ③ Armless chair base
1pc



- ④ Armless chair cushion
1pc



- ⑤ Chrome leg
8 pcs



- ⑥ Gold leg
8 pcs



+ Hardware Included

- A** Allen wrench
1 pc




- B** Bolt M8"*35mm
24pcs



- C** Washer M8*16mm
24 pcs




- D** Connect metal plate
100*75*18mm
2 pcs




ASSEMBLY INSTRUCTIONS

1



2

Remove the cushion from each product.



3

Assemble connect metal plate, then put cushions back on the seat.

