


Instruction Manual

Table Lamp Set of 2



Overview



Assembly Instruction

1. Rotate Socket assembly C counter-clockwise by two turns, then screw Socket assembly onto Lamp base B and tighten.
2. Insert Harp F into Saddle D.
3. Install E26 bulb E (not included) into socket.
4. Attach assembled Lamp shade G onto Harp F and tighten it with Finial H.

Product Specifications

| | |
|---------------|----------|
| Input voltage | 120V |
| Rated power | 100W MAX |
| USB port | 5V 2A |
| Lamp socket | E26 |
| Cord Length | 5ft. |

Product Packaging

| | |
|--------------------|-----|
| Lamp base assembly | × 2 |
| Lamp shade | × 2 |
| Harp&Finial | × 2 |
| Lamp manual | × 1 |

Safety Warning:

BULB TYPE:


Use only the bulb type and wattage indicated on Wattage Label placed on or near socket.

WARNING: NEVER EXCEED MAXIMUM WATTAGE Indicated as bulb may cause fire.

CAUTION:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature. This plug can be used in a polarized outlet only one way. If plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician.

DO NOT ALTER THE PLUG!



PROPER LAMP CARE:

Use a soft cloth to dust your lamp on a regular basis. Never use chemicals or an abrasive cleaner, to do so may damage the finish on your lamp.

TROUBLESHOOTING:

If fixture does not work:

1. Turn off electrical power and check all wire connections.
2. Check fuse or circuit breaker and replace if necessary.
3. Check to make sure light bulb is in working order.