




# ASSEMBLY INSTRUCTIONS




## +Parts Included

① Legs (2 pcs)

② Seat frame (1 pc)



③ Seat cushion (1 pc)



## +Do Not Use Power Tools



## +Suggested Adults



## NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

## 1 IMPORTANT SAFETY INFORMATION

- Do not** assemble the product if the parts arrived damaged.
- Do not** assemble if Hardware parts are missing.


## 2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

## +Parts Included


A. Bolt  
Ø8x50mm (6 pcs)

B. Spring Washer  
Ø8xØ12mm (6 pcs)




C. Flat Washer  
Ø8xØ19mm (6 pcs)

D. Dowel  
Ø10xØ30mm (4 pcs)




E. Allen Key (1 pc)




# ASSEMBLY INSTRUCTIONS

①



②



# ASSEMBLY INSTRUCTIONS

3

