



# KITCHEN ISLAND CART


SKU N707P472757

SKU N707P472758


Assembly instructions-Please keep for future reference




Important-Please read these instructions fully before starting assembly




**QUICKFIT:** Tighten quickfit until shoulder is flush with panel.  
Do not overtighten or undertighten.



**LOCK:** When fitting cam lock, ensure starting position is correct  
before you insert connecting quickfit.






Quickfit head should be in the centre of the  
cam lock when the two panels are joined.  
Cam lock should be inserted before quickfit.














Turn cam lock clockwise to tighten.

# Assembly Instructions

















BOX:N707P472757

| NO. | PARTS                                                                               | QTY |
|-----|-------------------------------------------------------------------------------------|-----|
| 3   |    | x1  |
| NO. | PARTS                                                                               | QTY |
| 4   |    | x1  |
| NO. | PARTS                                                                               | QTY |
| 5   |   | x1  |
| NO. | PARTS                                                                               | QTY |
| 11  |  | x2  |
| NO. | PARTS                                                                               | QTY |
| 12  |  | x2  |
| NO. | PARTS                                                                               | QTY |
| 26  |  | x2  |
| NO. | PARTS                                                                               | QTY |
| 27  |  | x2  |








| NO. | PARTS                                                                                 | QTY |
|-----|---------------------------------------------------------------------------------------|-----|
| 28  |    | x4  |
| NO. | PARTS                                                                                 | QTY |
| 29  |    | x4  |
| NO. | PARTS                                                                                 | QTY |
| 30  |   | x4  |
| NO. | PARTS                                                                                 | QTY |
| 31  |  | x4  |




BOX:N707P472758

| NO. | PARTS                                                                               | QTY |
|-----|-------------------------------------------------------------------------------------|-----|
| ①   |    | x1  |
| NO. | PARTS                                                                               | QTY |
| ②   |    | x1  |
| NO. | PARTS                                                                               | QTY |
| ⑥   |   | x2  |
| NO. | PARTS                                                                               | QTY |
| ⑦   |  | x1  |
| NO. | PARTS                                                                               | QTY |
| ⑧   |  | x2  |
| NO. | PARTS                                                                               | QTY |
| ⑨   |  | x1  |
| NO. | PARTS                                                                               | QTY |
| ⑩   |  | x2  |










| NO. | PARTS                                                                                 | QTY |
|-----|---------------------------------------------------------------------------------------|-----|
| ⑬   |    | x1  |
| NO. | PARTS                                                                                 | QTY |
| ⑭   |    | x1  |
| NO. | PARTS                                                                                 | QTY |
| ⑮   |   | x1  |
| NO. | PARTS                                                                                 | QTY |
| ⑯   |  | x1  |
| NO. | PARTS                                                                                 | QTY |
| ⑰   |  | x1  |
| NO. | PARTS                                                                                 | QTY |
| ⑱   |  | x1  |
| NO. | PARTS                                                                                 | QTY |
| ⑲   |  | x1  |


BOX:N707P472758

| NO. | PARTS                                                                               | QTY |
|-----|-------------------------------------------------------------------------------------|-----|
| 20  |    | x2  |
| NO. | PARTS                                                                               | QTY |
| 21  |    | x2  |
| NO. | PARTS                                                                               | QTY |
| 22  |   | x1  |
| NO. | PARTS                                                                               | QTY |
| 23  |  | x1  |
| NO. | PARTS                                                                               | QTY |
| 24  |  | x2  |
| NO. | PARTS                                                                               | QTY |
| 25  |  | x5  |
| NO. | PARTS                                                                               | QTY |
| 32  |  | x1  |


| NO. | PARTS                                                                                               | QTY |
|-----|-----------------------------------------------------------------------------------------------------|-----|
| 33  |                  | x3  |
| NO. | PARTS                                                                                               | QTY |
| 34  |                  | x2  |
|     | <br>Hardware kit | x1  |

BOX:N707P472758


|                                                                                                                |                                                                                                                |                                                                                                                |                                                                                                               |                                                                                                                   |                                                                                                                  |                                                                                                                  |
|----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|
| <b>A</b> x74+5<br>            | <b>B</b> x74+5<br>            | <b>C</b> x2<br>               | <b>D</b> x4+1<br>M6x40mm<br> | <b>E</b> x4+1<br>M4x40mm<br>    | <b>F</b> x82+5<br>M3x12mm<br> | <b>G</b> x48+4<br>M4x12mm<br> |
| <b>H</b> x4+1<br>             | <b>I</b> x8<br>               | <b>J</b> x44+4<br>M6x30mm<br> | <b>K</b> x2<br>              | <b>L</b> x2<br>                 | <b>M</b> x3<br>               | <b>N</b> x1<br>               |
| <b>O</b> x8<br>               | <b>P</b> x8+1<br>M4x12mm<br>  | <b>Q</b> x8+1<br>M4x14mm<br>  | <b>R</b> x8<br>              | <b>S</b> x22+2<br>M3.5x16mm<br> | <b>T</b> x1<br>               | <b>U</b> x8+1<br>             |
| <b>V</b> x28+2<br>M5x40mm<br> | <b>W</b> x20+1<br>M6x10mm<br> | <b>X</b> x20+1<br>M6x20mm<br> | <b>Y</b> x18+2<br>           |                                 |                                                                                                                  |                                                                                                                  |




x4




CL





CR



DL



DR




## friendly reminder

To avoid errors and confusion during the installation of accessories, use the type and quantity of hardware accessories according to the installation procedure described in the instructions. First, unroll the accessories bag and lay out the hardware accessories, cut holes in the side, and take out the hardware accessories



Assembly Steps


1



A x8




2




B x1




J x2




M6x30mm





B x2




J x2




M6x30mm




B x1






J x2



M6x30mm









F x6



I x2




J x4



V x6





A x4





F x2



M3x12mm

CL x1








F x6



I x2





D x4



H x4





A x4






F x2



M3x12mm

CR x1



A x4





F x2



M3x12mm

CL x1





A x4






F x2




M3x12mm

CR x1





B x4












B x4





B x4






B x4






K x2



X x20





M6x20mm



J x6




V x6




A x12








A x8



B x8







B x12



J x12



M6x30mm



L x2




M x3



W x20



M6x10mm



F x8




CL x2




CR x2




x2



E x4



M4x40mm




C x2



F x12



M3x12mm




F x24




M3x12mm


I x4









A x14





B x14




J x10



M6x30mm







F x2



M3x12mm

N x1



A x16



O x4




P x8




M4x12mm

x2





×4


V x16



×2

B x16





F x16




DL x4





DR x4






x4





U x8



G x16



M4x12mm

O x4



Q x8




M4x14mm



R x8






x2




If the door can't close,  
please adjust the hinges.



This is used to  
adjust the door  
panel in the up and  
down direction.




This is used to adjust the door panel in the front and back  
direction: Loosen the screw first, and then tighten screw  
after adjusting the door panel to the proper position.





G x32



M4x12mm



S x22



Y x18

