
User Manual

Basketball Backboard



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

USER MANUAL

General Safety Instructions








● Two capable adults are required for this assembly.
● Read and understand the manual before assembling and using the unit.
● Failure to follow the instructions could result in injury or damage to the property.
● Select a safe place to install the backboard.
● Use extreme caution when using ladder.
● Make sure the backboard is firmly installed.
● Do not hang from the backboard and rim.
● Remove all contents from box and make sure this matches the parts list.
● Do not return the product in store, please contact customer service.

Maintenance

1. Regularly check if the backboard is firmly attached on the wall or mounting bracket. It is required to tighten if the screws are loose.
2. Check your basketball system frequently for loose hardware, excessive wear; and signs of corrosion.

For safety reasons, and to prolong the life of your basketball system, you must take the following preventative measures.
(1) Check all nuts and bolts. If any are loose, tighten them.
(2) Check all parts for excessive wear and tear. If necessary replace any parts that have been worn or damaged through usage. Contact our Customer Service Department for replacement parts.
Note: DO NOT HANG FROM RIM


Part List

	DESCRIPTION	PART IMAGE	Qty
1	Wall plug		8
2	Bolts		8
3	Washer		8
4	Backboard		1
5	Net		1
6	Rim		1
7	Tools		1

Assembly


Step 1

Find a suitable wall/board for ball-shooting.




Step 2

Place the backboard(#4) on desired areas to navigate & prepare for drilling.



Step 3

Drill the wall/board according to the location of the backboard, and stuff the Wall plug (#1 * 8) into the hoes.



Step 4


Locking the basketball hoop.


● Align the backboard (#4) with the corresponding hoes, and put in 4 sets of Bolts (#2) and washer (#3). Tighten the screws.

● Align the Rim (#6) with 4 hoes located at the bottom of the backboard, and put in 4 sets of Bolts (#2) and washer (#3). Tighten the screws.

● Hang the basketball net (#5).

● Assembly Complete.




6
5
①
②
③
④