
Assembly Instructions

CAUTION: You must read this before you proceed.

Please look in the Seat Panel for hardware packs.


ARMLESS CHAIR




CAUTION : This Chair is NOT a TOY.

Keep your child / children at bay in the process of assembly. For turning the Chair and to prevent damage to the Chair, 02 persons may be needed to execute this action.

Parts List			
No.	Picture	Description	Qty
A		Backrest Panel	1
В		Left Arm Panel With Pre- installed Levellers	1
с		Right Arm Panel With Pre- installed Levellers	1
D		Seat Panel	1
E		Support Bar	1
F		Seat Cushion	1
G		Back Cushion	1
Hardware			
No.	Picture	Description	Qty
1		Bolts (M6x35mm)	7
2		Screws (M6x45mm)	5
3		Allen Key	1






Place the Right Arm Panel (C) with inside face skywards onto a clean, soft surface to avoid any scratches or damages to the product.

Step 2.1: Align the dowels of Support Bar (E) into the positions in the Right Arm Panel (C).

Then, affix Support Bar (E) with Right Arm Panel (C) by using Bolt (1) and Allen Key (3).

Step 2.2: Attach the Backrest Panel (A) onto Right Arm Panel (C) by using Bolts (1) and Allen Key (3).

DO NOT FULLY TIGHTHEN BOLTS.




Place Left Arm Panel (B) onto the assembled frame from Step 2 Step 3.1: Align the dowels of Support Bar (E) into the positions in the Left Arm Panel (B).


Then, affix Support Bar (E) with Left Arm Panel (B) by using Bolt (1) and Allen Key (3).


Step 3.2: Pre-attach the Left Arm Panel (B) onto Backrest Panel (A) by using Bolts (1) and Allen Key (3) as shown above.

DO NOT FULLY TIGHTHEN BOLTS.



Note: Using Screws (2) from inside to outside of Seat Panel (D) **DO NOT FULLY TIGHTHEN SCREWS.**





<u>Care & Maintenance</u>			
•	Do not put hot items directly on furniture surface		
•	Do not clean furniture with harsh cleansers or polish.		
~ Ö. •	To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended.		
◎ 🏋 •	Children should not climb or jump on the furniture.		
	Do not write on furniture without a padded barrier to protect the surface.		
✓ <u>↔</u> •	To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.		
	Not for commercial use. For residential use only .		
	Stains may be removed with mild soap solution and damp cloth.		
✓ <> ●	Dust and pick-up spills using a clean, non-colored, lint-free cloth .		