


Assembly Manual

Dining Chair


AC022




Please read this manual carefully before any operation and keep it properly for future use.

If any problems on our product, please feel free to contact us at ecservice@isunon.com.


Assembly-note:




- ① Put a protective mat on the ground and handle the product with care.




- ② Two people are preferred.



- ③ Contact us if you have any confusions




Exploded
diagram:



NO.	Name	PCS
1	Backrest with rear legs	1
2	Seat	1
3	Front leg	1

Accessory list:


A		B		C	
					
Bolt	8+1	Allen wrench	1	Decorative cove	8+1

Note: The number after "+" sign indicates the extra piece(s).

Step1:

Place the seat pan with back(2) on the carton, then attach back (1) to the seat pan using bolts(A) and allen key(B) .Do NOT fully tighten the bolts until all of them are in the correct holes. This will allow you slight adjustments during the assembly.

1




(A) 
(x4)

Step2:

Attach front leg(3) to the seat using bolts(A) and allen key(B). Do NOT fully tighten the bolts until all of them are in the correct holes. This will allow you slight adjustments during the assembly.

2




A
(x4)

Step3:


Insert the decorative covers(C) to the holes and the assembly is done.

3



Ⓒ
(x8)

Done



Warning

- Please keep the product away from children while assembling.
- Do not let children play or jump on the product.
- Do not stand on the item or use as a step ladder.
- Prior to use, please check to see if there's any loosening screw or part.
- Make sure that each screw and part is correctly installed and securely fastened.

Care and Maintenance

- Use a soft clean cloth that will not scratch the surface when dusting
- There's no need to use furniture polish.If you need, test it first in an inconspicuous area.
- Using solvents of any kind on your furniture may damage the finish.
- Never use water to clean your furniture as it may cause damage to the finish.
- Liquid spills should be removed immediately.
- Gently blot the spill with a soft clean cloth to avoid rubbing.

Further advice about the furniture care

- It is best to keep your furniture in a climate-controlled environment.
- Extreme temperatures and humidity changes can cause fading.warping, shrinking and spitting of wood.
- We recommend to keep furniture from sunlight exposure to avoid possible surface damage.
- Proper maintenance and cleaning at home will extend the life of your purchase.
- Following these important and helpful tips will help retain your furniture's performance even when it ages.
Periodically(every 90 days) make sure the screws are fully tightened.