

Patio Umbrella

Instruction manual



Contact Information

For assistance or support, please contact our customer service team. We're committed to resolving your concerns promptly.

- ✉ help@icosiest.com [24/7]
- ☎ (909)312-3668 [9AM-5PM(PT) Monday to Friday]

As a valued customer, your satisfaction is our TOP priority!

Assembly Instructions

BEFORE YOU BEGIN:






- Please read all instructions thoroughly before starting assembly
- Keep these instructions for future reference
- Verify all components and hardware against the parts list
- Follow each step in sequence for proper assembly

IMPORTANT SAFETY NOTES:





- Assemble the product close to its intended location to avoid unnecessary moving
- Place the product only on flat, stable surfaces
- WARNING: Keep small parts and packaging materials away from children – choking hazard

- SKU NO.**
C190200002
C190200003
C190200004
C190200005
C190200006
C190200007
C190200008
C190200009





Packing List

NO.	PICTURE	QTY
L		1
B		1
D		1
F	 (M8X20)	4
H		1

Packing List

NO.	PICTURE	QTY
J		1
M		1
A		1
C		1
E	 (M8X15)	4

Packing List

NO.	PICTURE	QTY
G	 (Ø8)	8
I	 (M8)	1
K		1
N		1

Return / Damage Claim Instructions

- **DO NOT discard the box / original packaging.**

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

- **Take a photo of the box markings.**

A photo of the markings (text) on the side of the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

- **Take a photo of the damaged part (if applicable).**

A photo of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

- **Send us an email with the images requested.**

Email us directly from marketplace where your item was purchased with the attached images and a description of your claim.

How satisfied are you with our products? Your comments mean a lot to us!

Find more awesome deals on <http://www.icosiest.com>


For latest information, follow us on [facebook.com/icosiest](https://www.facebook.com/icosiest)

For daily design inspirations, like us on [instagram.com/icosiest_furniture/](https://www.instagram.com/icosiest_furniture/)

Product Assembly

01

Remove components A and B, position them vertically, place component D atop them, and secure using screws F and washers G. After installing all four screws, utilize wrench I to tighten them completely.




Important:

After installing all four screws on crosspieces A and B, proceed to tighten them completely with a wrench.

Product Assembly

02

Remove component C and attach it with screws E and washers G. Once all four screws are installed, use wrench I to tighten them completely. Subsequently, components H and N may be fitted.




NOTE:

NOTE:
Counterweight blocks of 180LB or more must be utilized prior to deploying the umbrella.

Product Assembly

03

Insert umbrella frame L into umbrella stand tube C, then securely fasten the handwheel screw J. Next, release the binding straps securing the umbrella canopy. Important: Ensure the orientation of the holes on the umbrella pole aligns with those on the umbrella stand tube.




NOTE:

The base is sold separately, You can buy it at other online store

Product Assembly

04


Gently extend umbrella frame L outward, then draw out the telescopic pole from within the rib. When the Positioning buckle on the telescopic pole is fully extended from the rib, slide the canopy over it.



Product Assembly

05


1. Firmly grasp the sliding sleeve and inner handle.
2. Elevate the frame to a comfortable height.
3. Rotate the crank handle clockwise to deploy the umbrella at various angles.



Product Assembly

06


Depress the pedal of the turntable D and The umbrella pole features multiple positioning holes rotate the umbrella pole to achieve 360° allowing for canopy adjustment canopy rotation.



Product Assembly

07

1. Firmly grasp the sliding sleeve and the inner handle.
2. adjust the frame to a comfortable position.
3. Rotate the crank handle counterclockwise to retract the umbrella.



Product Assembly

08

After retracting the umbrella, secure the frame with the binding straps.

