









ASSEMBLY INSTRUCTION








LOCATION OF LOVESEAT CONSOLE:
CHECK BEHIND
LOWER BACK OF THE LOVESEAT.
OPEN FLAP TO FIND A ZIPPER COMPARTMENT.

LOVESEAT

| | |
|---|--|
|  <p>A</p> | <p>①</p>  |
|  <p>B</p> <p>2PC</p> |  <p>C</p> <p>1PC</p> |
|  <p>D</p> <p>1SET</p> |  <p>E</p> <p>3PC</p> |
| <p>②</p>  <p>Console backrest C</p> | |
| <p>③</p>  <p>Adapter and power cords are underneath the sofa</p> <p>CLOSE Lamp light OPEN USB</p> <p>AC Adapter</p> | |


ASSEMBLY INSTRUCTION

SOFA

| | |
|--|---|
|  <p>A</p> <p>1PC</p> | <p>①</p>  |
|  <p>B</p> <p>3PC</p> | <p>②</p>  |
|  <p>C</p> <p>1SET</p> |  |
| <p>③</p>  <p>wireless charging</p> <p>touch</p> <p>CLOSE Lamp light OPEN USB</p> <p>AC Adapter</p> | |


ASSEMBLY INSTRUCTION

CHAIR



ASSEMBLY INSTRUCTION

LOVESEAT



ASSEMBLY INSTRUCTION

SOFA

