


HIGH STORAGE WINE RACK





**FOR REPLACEMENT PARTS OR HELP WITH
ASSEMBLY PLEASE CONTACT US**

**PLEASE ENSURE TO HAVE THE MODEL #
FROM THE PACKAGING OR INSTRUCTION BOOKLET**

**TO RETURN THE PRODUCT:
PLEASE CONTACT THE RETAILER
WHERE THE ITEM WAS PURCHASED FROM**

IMPORTANT : Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

SAFETY INFORMATION

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required. Hardware package may have spare parts.

WARNING: This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.

May require 2 people for ease of assembly.

CARE and MAINTENANCE

To clean, use a soft or slightly damp cloth, then wipe with a clean, dry cloth. Dust with soft dry cloth.

Do not use ammonia-based cleaning products, as they will damage the finish. Do not leave liquids or damp cloths on this furniture.


To avoid dulling of the finish, do not place furniture in direct sunlight.

Please inspect and tighten all screws or bolts on a regular basis to ensure proper performance and safety of your item.

PRE-ASSEMBLY INFORMATION


PART DESCRIPTION

A




TOP
QTY 1

B




SIDE
QTY 1 PAIR

C




DIVIDER
QTY 9

D




BOTTOM SHELF
QTY 1

E




TOP SHELF
QTY 1

F




CENTRE SHELF
QTY 2

G




CABINET SHELF
QTY 2

H



DOOR
QTY 1

I



BACK PANEL
QTY 1

NEED HELP? For help with assembly or if you are missing a part,
Please call customer service

PRE-ASSEMBLY INFORMATION


HARDWARE DESCRIPTION

1



ALLEN KEY SCREW
M6 X 30mm
QTY 6

2



CAM LOCK PIN
CAM LOCK
QTY 10 SETS

3



WOOD DOWEL
Ø8 X 30mm
QTY 20

4



ALLEN KEY
QTY 1

5




PHILLIPS SCREW
ROUND HEAD
M4 X 15mm
QTY 15

6




SHELF SUPPORT
QTY 12

7




HANDLE
M4 X 25 mm
QTY 1 SET

8




PHILLIPS SCREW
M3 X 15mm
QTY 4

9




MAGNET AND PLATE
QTY 1 SET

10



PHILLIPS SCREW
M3 X 12mm
QTY 6

11




PHILLIPS SCREW
M4 X 30mm
QTY 18


12



- a.  M4 X 25mm - 1PC
 - b.  M4 X 15mm - 1PC
 - c.  M4 X 25mm - 1PC
- TIPPING RESTRAINT
QTY 1 SET




Required -
Flathead screwdriver
Phillips screwdriver
Rubber mallet
Not Included




NEED HELP? For help with assembly or if you are missing a part,
Please call customer service

COMPONENTS-KEY DIAGRAM




ASSEMBLY

STEP-1



1. Attach 3 Dividers (C) to Centre Shelf (F) using 6 Phillips Screws (11).
2. Use Phillips screwdriver to snugly tighten screw.
3. Repeat Step-1 for the second Centre Shelf (F) and other 3 Dividers (C).


STEP-2



1. Attach 3 Dividers (C) to Bottom Shelf (D) using 6 Phillips Screws (11).
2. Use a Phillips screwdriver to snugly tighten screw.

ASSEMBLY


STEP-3



1. Insert 8 Dowels (3) into pre-drilled holes on Top Shelf (E) and Bottom Shelf (D) (2 dowels on each side).
2. Insert 12 Dowels (3) into pre-drilled holes on 2 Centre Shelves (F) (6 dowels on each Centre Shelf).
3. Use rubber mallet to tap Dowels (3) into bottom of holes securely. 1/2 length of Dowels should be exposed.
4. Attach 5 Cam Lock Pins (2) to each Side (B) using guide holes.
5. Align Cam Lock Pins with pre-drilled holes on Bottom Shelf (D) and Top Shelf (E).
6. Insert 10 Cam Locks (2) into pre-drilled holes on Bottom Shelf (D) and Top Shelf (E) (6 Cam Locks on Bottom Shelf (D) and 4 Cam Locks on Top Shelf (E)).
7. Use flathead screwdriver secure Cam Locks.

ASSEMBLY


STEP-4



1. Attach Top (A) to Sides (B) and using 6 Allen Key Screws (1) (3 screws on each Side).
2. Use Allen Key (4) to tighten Screws. Do not over-tighten.

ASSEMBLY


STEP-5



1. Attach Back Panel ① to back frame of wine rack using 15 Phillips Screws Round Head ⑤ through pre-drilled holes.
2. Use Phillips Screwdriver to tighten screws.

ASSEMBLY


STEP-6



1. Attach hinges on Door (H) to Side (B) using Phillips Screws (10) into guide holes.
2. Attach Magnet Plate (9) to corners of Door (H) using Phillips Screws (8) into guide holes on Doors (H).
3. Attach Magnet (9) using Phillips Screws (8) into guide holes on Top Shelf (E).
4. Use Phillips screwdriver to snugly tighten screw.
5. Use Phillips screwdriver to attach Handle (7) to Door (H).

ASSEMBLY

STEP-7




1. Use 4 Shelf Supports ⑥ for each Cabinet Shelf ⑦ in desired location.
2. 2 Shelf Supports ⑥ may be used on back top of each Cabinet Shelf ⑦ as a tipping restraint.


ASSEMBLY

NOTE: Injuries and damage can occur from furniture tip-over. It is important to use the safety bracket included. If the tipping restraint kit is not in the box, please contact our customer service department in order to obtain another kit before using the furniture.

STEP-8



NOTE: The screwdriver is not included in the hardware pack.



1. To attach Tipping Restraint ⑫, follow instructions on Tipping Restraint package.

When you determined the location for your unit, install the Furniture Tipping restraint. Carefully follow the instructions contained on the package.

WARRANTY

Thank you for purchasing our product. These products have been made to demanding, high-quality standards and are guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase. This warranty does not affect your statutory rights.

In case of any malfunction of your product (failure, missing parts, etc.) please contact us at our toll free service line or by email.

We reserve the right to repair or replace the defective product, at its discretion.

This product is guaranteed for 12 months if used for normal purposes. Any warranty is invalid if the product has been overloaded or subject to neglect, improper use or an attempted repair by other than an authorized agent. Heavy-duty or daily professional/commercial usage are not guaranteed.

Due to continuous product improvement, we reserve the right to change the product specifications without prior notice.