


sku:KX-27047CM

Aluminium steel 3-seater couch



Thank you for choosing us!

Our goal is to provide high quality outdoor furniture with outstanding customer service-all at an affordable price.

Please let us know how we are doing!

Problems?

(Missing pieces, wrong pieces...)

We will fix it immediately. Send us an email at

aftersaledirect@gmail.com.

Happy?

Please leave us a review!

You can make others happy too!



**IMPORTANT, RETAIN FOR
FUTURE REFERENCE:
READ CAREFULLY.**

Safety

- ☒ For domestic use only.
- ☒ Always use on firm level ground.
- ☒ Don't tighten all the bolts before the product is fully assembled.
- ☒ It would be useful to ask someone to help you assemble the product.
- ☒ Periodic structural checks of this product should be undertaken, do not use if you have any doubts about its fitness for purpose.
- ☒ Do not stand on the seat.
- ☒ Do not sit on the armrest.
- ☒ Do not let children play with this product.

At the beginning of the season


- ☒ Check to ensure that all components and fixings of this product are secure, do not use if you have any doubts about its fitness for purpose.

At the end of the season


- ☒ This product should be stored under cover during prolonged spells of adverse weather (wet or cold) and also during the winter (ideally in a garden shed or garage).
- ☒ Always clean and dry thoroughly before storage.

How to Put on the Cushion Cover

1




OR




1. Take the cushion covers and inners out of the carton.

2




2. Fold the inner in half, pushing the sides together, then begin to slide the cover onto it.

3




3. Align both far corners, then gently compress insert while fitting cover around it.

4



4. To avoid a stuck zipper, please pull the fabric away from the zipper before moving forward.

5



5. When all done, please pat the cushion or give it a little shake to make it more flat.

Care & Cleaning Guidelines


The covers are machine washable. Before washing, please zip the cover up to avoid catching other clothes
You can clean the dust on the chair / table / footstool with a damp cloth.

NOTE:

Vaccum compressed cushions,
Will return to normal shape after 5-7 days use.



COMPONENT LIST - COUCH SOFA

Item no.	Reference Image	Description	Qty.
A		Right Armrest	1
B		Left Armrest	1
C		Seat Base	1
D		Seat Cushion	3
E		Back Cushion	3
F		Washer	10
G		M6X30 Head Cap Screw	8
H		M6X20 Head Cap Screw	2
I		Cap	2
J		Allen Key	1



NOTE:

Do NOT tighten any screws fully first until you have tightened all the screws.

This may cause the frame to warp.

If there is still wobbles or screw holes cannot be aligned, loosen the screws and tighten sequentially.

If the Couch is not stable it could lead to damage to the product.

01**(F)****Washer ×1****(H)****M6*20 Screw ×1****NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.**

02

(F)




Washer x1

(H)



M6*20 Screw x1



NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

03

(F)




Washer x4

(G)



M6*30 Screw x4



NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

04

F






Washer x2

G



M6*30 Screw x2



NOTE:TIGHTEN THE SCREWS COMPLETELY.

05

F




Washer x2

G





M6*30 Screw x2



NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

06

Tighten all 10 Screws into place with Allen Key (J) and Install the Caps(I) for protecting and concealing the screws.



NOTE:IF ANY SCREW HOLES CANNOT BE ALIGNED, LOOSEN ALL THE SCREWS AND GO BACK STEP 1 AND RESTART ASSEMBLY.

07

