


Assembly Instructions




End Table



Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.

Warm Tips


1. Carefully read these instructions and keep them for future reference.
2. Check the parts list and confirm everything's there before starting assembly.
3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.










X2




When using the electric screwdriver ,
Reduce the power and torque to avoid damaging the furniture



?













⚠ Caution

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.


Parts List






Hardware List

A	x9	B	x9	C	x4	D	x1
							
M6x12		M6x30		Ø19xM6*15			


1






screwdown  100% 

A	X4
	
M6X15	

2






screwdown  100% 

A	X4
	
M6X15	

3



screwdown 100%




B	X4
	
M6X30	



4

screwdown 100%



B	X4
	
M6X30	

5



C	X4
Ø19XM6*15	

Thank you for your support!

