


# ASSEMBLY INSTRUCTION



## WARRANTY:

We stand behind our products & service with confidence! If parts damaged or missing please feel free to contact us for a FREE REPLACEMENT.

We warranty this product to be free from defects in materials. This warranty covers one year from the date of original purchase.

## NOTES:












- The item is only intended to be used indoors. The product must be assembled and used in accordance with the provisions of the manual.
- It is recommended that assembly is undertaken by about 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outlined. Estimated assembly time is 30 minutes.

## WARNING:

- **WARNING FOR YOUNG CHILDREN** - This product contains small components, please ensure that they are kept away from small children while assembling.

# 1

# PARTS LIST

| A   | B   | C   | D  | E   | a   | b   |
|---|---|---|--|---|---|---|
|  |  |  |  |  |  |  |
| 2PCS  | 9PCS  | 2PCS  | 1PCS   | 1PCS  | 1/4*37<br>4PCS  | 1/4*30<br>18PCS   |
| c   | d   | e   | f  |   |   |   |
|  |  |  |   |   |   |   |
| 4PCS  | 4PCS  | 1PCS  | 1PCS   |   |   |   |


## IMPORTANT:

Please check parts list before you start to assembly.If parts damaged or missing.Contact your seller for a FREE REPLACEMENT.Please provide your order number,a brief message about the issue,and your shipping address. Thank you!


# 2

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED

①




②



3

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED



**IMPORTANT: Please completely tighten all the bolts and nuts.**