






# Assembly Manual


1/2



A




X4




X2




X24




X4






X2




X4



A(X4)  
B(X2)  
C(X24)




X2



X4



96pcs




1pcs

Page 1


Page 2

D(x4)




Page3

E(x2)




Page4

F(x4)  
G(x2)  
H(x4)



Page5



Page6