


PLATFORM BED USER MANUAL



THANK YOU FOR YOUR PURCHASE

Thank you for choosing our product. NOTICE: Read this manual carefully before assembly or use to prevent damage caused by improper handling. If this product is transferred to a third party, this manual must be included. If you have any questions, please contact our customer support team.

INFORMATION TO THE USER

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

WARNING: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

CHARGER STATION INSTRUCTION

Read the instruction manual and strictly observe all safety warnings before use.

Specifications: Pay special attention to the following ratings if using this product outside the U.S.

Rating: 12A 125V~ 60Hz 1500W

USB Output: 5VDC Max.2A

Caution:

To Reduce the Risk of Electric Shock. Use only indoor in dry locations.

Suitable for Household (Residential) use only.

DO NOT PLUG INTO ANOTHER RELOCATABLE POWER TAP OR AN EXTENSION CORD.

General

To ensure compliance with safety standards, strictly adhere to the following guidelines when using this power supply:

1. For use with information technology and office equipment only.
2. The total output power drawn must not exceed the stated rating on the power supply.
3. This unit contains no user-serviceable parts. Do not attempt to repair the charger in the event of a failure or component defect.
4. The external power cord cannot be replaced. If the cord becomes damaged, the entire unit must be safely discarded.
5. To disconnect the unit from AC power, remove the plug from the wall outlet.
6. Ensure the wall outlet is located near the equipment and remains easily accessible.
7. DISPOSAL: Do not dispose of this product as unsorted municipal waste. It must be collected separately for proper recycling and treatment.
8. When connecting to a power source outside the U.S., use a properly configured plug adapter for the local wall outlet.

WARNING



Read all instructions carefully and keep them for future reference.
If this product is passed to a third party, then these instructions must be included.

⚠ WARNING To reduce the risk of burns, fire, electric shock, or injury to persons:

- Read all instructions before using this furnishing.

⚠ DANGER To reduce the risk of electric shock, always unplug this furnishing from the electrical outlet before cleaning or servicing.

⚠ WARNING Risk of injury. Keep children away from the footrest.

⚠ CAUTION Risk of injury and fire! Connect only to the furnishing specified in this manual.

- Unplug from the outlet before assembling or removing parts.
- Close supervision is necessary when this furnishing is used by or near children or persons with disabilities.
- Use this furnishing only for its intended use as described in these instructions.
Do not use attachments not recommended by the manufacturer.
- Do not operate this furnishing if it has a damaged cord or plug, if it is malfunctioning, or if it has been dropped, damaged, or submerged in water.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening.
- Do not use outdoors.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- To disconnect, turn all controls to the "OFF" position, then remove the plug from the outlet.
- To reduce the risk of electric shock, this furnishing is equipped with a polarized plug (one blade is wider than the other).



















This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.



















Before first use


- Check the product for any shipping damage.
- Remove all packaging materials.
- Before connecting the unit to a power source, ensure that the local voltage and current ratings match the specifications listed on the product's rating label.

⚠ DANGER **Suffocation hazard!** Keep all packaging materials away from children. These materials pose a potential suffocation hazard.


PARTS LIST

A1 	1×	A2 	1×	B 	1×
C 	12×	D1 	1×	D2 	1×
D3 	1×	D4 	1×	E1 	1×
F1 	1×	F2 	1×	V1 	1×
V2 	1×	G1 	1×	H1 	1×
H2 	1×	I 	2×	J 	2×

K	2×	L	24×	O1	4×
					
P	4×	Q	4×	R	4×
					
S	16×	T	4×	W1	4×
					
W2	4×	X	1×	U1	20×
					M6×15
U2	16×	U3	4×	U4	9×
	M6×10		M6×15		M8×50
U5	6×	U6	26×	U7	4×
	M8×35		M8×16		M8×10

U8	2×	U9	1×	U10	1×	U11	1×
							




EXPLODED VIEW





ASSEMBLY

Before your installation, please make sure that you have all the parts listed on the manual. If you find something missing, stop installing and contact your supplier immediately.

NOTE: Please do not completely tighten all the hardware until the entire assembly is completed!





3




x4

4





x4


5




6 Do not mix up the two accessories.
They are different in length.



7




8




9


BACK VIEW




NOTE: Pay attention to the orientation of the hole positions.




10




11




12




13



14




15




Please **note** that the side with **EVA** is upward during installation.

16




17




18


Put the U3 screws into the hole and press it into the bottom of the "⚡" hole.



19



20



Made in China