
Swivel Glider Recliner Chair SF-25906A

Product ID. 7AP2V

Scan for Support
support@garvee.com



Distributed by
GARVEE.com


V2512313K8R

Recliner Assembly Instructions

Estimated Assembly Time in Minutes


☆ <15 ★ <45 ☆ 60+

- Your recliner comes packaged in one box.
- **DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.**
- Carefully remove all of the components from the packaging and set aside for assembly.
- Assemble on a soft surface to prevent scratching the finish.
- **Zip ties are used to secure your recliner cords and avoid damage - do not cut.**



Support Email：support@garvee.com
Customer Phone Service：+1 888 891 2855
Mon - Fri from 9AM to 5PM (PST)


Part List


Ⓐ 1 x Seat 

Ⓑ Left & Right Back Wings 

Ⓗ 1 x Massage Control 

Ⓒ 2 x Arm Pads 

Ⓓ 1 x Back Frame 

Ⓘ 1 x Power Code for Massage 


Ⓔ 1 x Back Cushion 

Ⓕ 1 x Spring Coil Cushion 


Ⓖ 2 x Cup Holder 


Assembly

Step 1




Take arm pads and back wings out from the bottom.






Distributed by Garvee
www.garvee.com


Assembly






Assembly

Step 2




* NOTE: Hold the handles on the armrest with both hands, pull it out horizontally until you hear two clicks, now the armrest is extended.

Step 3




Step 4




Assembly

Step 5 Open the velcro on the rear side of the seat cushion cover.




Step 6



Put spring coil pad inside of the seat cushion cover and zipped.


Step 7




Then put the whole seat cushion on the center of seat base correclty and tighten the velcro.

Assembly


Step 8



Step 9





Step 10



Assembly


Step 11






Assembly

Step 12



Function Display


Function 1



Use this puller to release the footrest when sitting on the chair. Then push your arms backwards to recline the chair all the way.Finally,close the footrest by pushing down your feet.

Function 2

The recliner with a gentle rocking motion moves back and forth horizontally and can swivel 360° (reclining angle can not be fixed).




Assembly

READ ALL INSTRUCTIONS

BEFORE USING THE ITEM

REMOTE CONTROL

Function of remote



Massage Intensity Levels

Intensity button:Click to cycle and switch vibration intensity; when turned on, the default intensity setting is M gear.

Heating button:Press to activate the heating function, press again to deactivate the heating function.

Massage mode

Massage duration

ON/OFF

Time button

Mode selection button:Click to cycle and switch the vibration mode, with the default mode at startup being M4.

Massage area

Support Email：support@garvee.com
Customer Phone Service：+1 888 891 2855
Mon - Fri from 9AM to 5PM (PST)