




ASSEMBLY INSTRUCTIONS

OF5017 ADJUSTABLE SWIVEL OFFICE CHAIR


1/3

HARDWARE LIST			
NO.	PART		Q.TY
1		Backrest	1pc
2		Seat Cushion	1pc
3		Base Plate	1pc
4		Base Tube	1pc
5		Air Rod	1pc
6		Plastic lid	1pc

PART LIST			
NO.	PART		Q.TY
A		4 Sc rews (M6X20mm)	4pc s
B		4 Screws (M6 X30mm)	4pc s
C		Hexagon Wren ch	1pc

STEP 1.


Pick up the Air Rod (5) and Base Tube (4) as shown. Insert the Air Rod (5) into the Base Tube (4). Then put it aside and we will use it in Step 4.



STEP 2.


Fix the Base Plate (3) to the bottom of the Seat Cushion (2). Tighten the Screws M6x20mm () with Hexagon Wrench () firmly.

*Caution: Make sure the 'FRONT' direction of Base Plate (3) and Seat Cushion (2) are the same.



STEP 3.


Fix the bottom of the Backrest (1) to the back of the Seat Cushion (2). Tighten the Screws M6X30mm (7) with Hexagon Wrench (8) firmly.




STEP 4

Pick up the Air Rod (5) and Base Tube (4). There's a hole in the middle of the Base Plate (3). Press the Seat Cushion (2) from top to bottom, use your whole body's strength to insert it firmly, the assembly is complete now.


*Caution: If the Air Rod (5) doesn't insert to Base Plate (3) firmly, it's likely to fall off when the chair rises up.



COMPLETED



Up and down adjustment



360° Rotation



Rocking Function

Thanks for purchasing our products. Please read this manual before assembly.
And please assemble in order. After the assembly, keep the instruction properly.
Make sure all the parts are included (8 kinds in total).

Do not fully tighten screws/ bolts
until completely assembled