

HEATED STADIUM SEAT

Power Bank Included



3 Heating
Settings



6 Reclining
Positions



Side
Pockets




Bleacher Hooks
& Straps




Adjustable
Carry Straps

HOW TO ACTIVATE THE HEATER FUNCTION

- 1 Make sure the cord is plugged into a battery pack.
- 2 Press and hold the heat button for 3 seconds to turn on the Heater.
- 3 There are 3 heating options in the seat. Press the heating button repeatedly to change to another heat setting indicated by the colors.



RED
High Heat



BLUE
Middle Heat



GREEN
Low Heat

WARNING!

1. Seat cannot be charged, please make sure to connect charging bank when using.
2. Caution for fire and other heat sources as this seat isn't fire proof.
3. Caution of sharp objects when using.
4. Warranty is not covering misuse. Please read above instructions carefully before use.
5. If your Heated Stadium Bleacher Seat does not perform to your expectations, please feel free to contact us on the order details page or send email to salesafterservice@outlook.com. We will try our best to solve it for you.
Your 100% satisfaction is our target.

WAY TO FOLD SEAT WITH ARMRESTS

1



Place chair in horizontal position facing down (straps facing upwards towards the ceiling) and apply pressure on armrests hinges with both hands.

2



Flip chair over (straps facing down, towards the floor).

3



Hold bottom seat down. With one hand. Push chair's backrest forward and upwards with other hand to one of the six reclining positions.

WAY TO FOLD SEAT WITHOUT ARMRESTS (FOR CREATING A LARGER SEAT)

1



Place chair in horizontal position facing up straps facing down, towards the floor) and apply pressure on armrests hinges with both hands.

2



Hold bottom seat down, with one hand. Push chair's backrest forward and upwards with other hand to one of the six reclining positions.

WAY TO CHANGE BACK POSITION AND LOCK SEATING POSITION



1 Hold bottom seat down, with one hand. Push backrest forward with other hand until reclining set position is released.



2 If the seat back cannot be locked, place the seat flat and raise the back again, paying attention to the clicking lock sound. Changing the position makes a clicking sound.

WAY TO CHANGE TO LOWER POSITION OR FLATTEN BACK POSITION




1 Hold bottom seat down with one hand. Push backrest forward with other hand until the angle between the seat cushion and the back is less than 90°.



2 Push backrest down to a horizontal position or lower reclining position.

WAYS TO SECURE THE SEAT TO THE BLEACHERS



Use Elastic Straps



2 Hooks are concealed under the bottom zipper and can lay flat inside when not in use.



POWER BANK USER MANUAL

Our stadium seats need to be connected to a power bank for heating(Note: Stadium seats cannot be charged.) So we are equipped with a 20000mAh power bank that comes with the package. Not just for our seats, the power bank is compatible with a wide range of devices and can charge almost any mobile device, including phones, tablets and more.

SPECIFICATIONS

Product Name: POWER BANK

Weight:About 401.9g

Battery energy : 74Wh


Output : 7.4V/3A(USB)Max

Model: XY-8230

Capacity : 3.7V/20000mAh(Max)

Input : 5V/2.1A(TYPE-C)Max

Output : 12V/3A(DC)Max



1 CHARGING

Connect the A male connector of Type-C cable to the power supply, and insert the other end of Type-C into the Type-C charge input port of this product. Then, the power indicator light on and starts flashing, the process of charging begins. When all 4 display lights are on, the power bank is fully charged.

2 DISCHARGING

After the device is connected, the process of discharging begins automatically. The power indicator light lights up and starts to output voltage for the device to use. The USB output port can support 7.4V3A while the DC output port supports 12v3A to the max extent possible. When the device is fully charged or the charging cable has been unplugged for 20 seconds, the power bank hibernates; long press the functional key switch to shut down.

WARNING!

1. Never put the power bank into water or get wet and rain.
2. Never throw, strongly beat, or shake the power bank or subject it to pressure or impact, otherwise it may damage the internal precision parts and intact structure.
3. Lithium-ion batteries suffer in extreme heat and cold, their capacity goes down, it may not work below -20°C.
4. When charging and discharging, the main host of power bank will become hot slightly, which is normal.