



ASSEMBLY INSTRUCTIONS




Notice:


1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service.
4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.



Recommended installers:2














Put a carpet on the floor
before unpacking



Estimate installation time:
30minutes






ASSEMBLY INSTRUCTIONS

PART LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
(A)		X1	(F)		X1
(B)		X1	(G)		X2
(C)		X1	(H)		X1
(D)		X1	(I)		X1
(E)		X1	(J)		X1
			(K)		X1

ASSEMBLY INSTRUCTIONS

HARDWARE LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
1	 Ø8*30mm	X24+2	7	 Ø3*15mm	X21+2
2		X20+2	8		X4
3		X20+2	9		X4
4	 Ø1/4"*1-1/4"	X2	10	 Ø3*14mm	X24+2
5		X2	11		X1
6		X2	12		X1

ASSEMBLY INSTRUCTIONS




ASSEMBLY INSTRUCTIONS

1




(B) 1PC (C) 1PC (4) 2PCS (5) 2PCS (6) 2PCS (1) 4PCS (2) 4PCS (11) 1PCS




ASSEMBLY INSTRUCTIONS


2



Ⓓ 1PC




Ⓔ 1PC



Ⓕ 1PC




② 8PCS




ASSEMBLY INSTRUCTIONS


3



③ 8PCS




① 8PCS




ASSEMBLY INSTRUCTIONS


4




(A) 1PC



(G) 2PC




(3) 4PCS



(1) 4PCS




(2) 8PCS




ASSEMBLY INSTRUCTIONS


5



(K) 1PC






(3) 8PCS



(1) 8PCS




Ø3*15mm
(7) 21PCS



ASSEMBLY INSTRUCTIONS




6



(H) 1PC




(8) 4PCS




ASSEMBLY INSTRUCTIONS

7



I 1PC



J 1PC




9 4PCS



Ø3*14mm

10 8PCS




ASSEMBLY INSTRUCTIONS

8




Ø3*14mm

⑩ 16PCS



ASSEMBLY INSTRUCTIONS

9




1

Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm




2

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm



3

Up-Down Direction Adjustment:


Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm

ASSEMBLY INSTRUCTIONS


10

Common Door Panel Issues:




ASSEMBLY INSTRUCTIONS

11




12 1set

A




1pcs

B




2pcs

C




Ø8*3/4"
1pcs

D




Ø8*1-1/2"
1pcs

E



1pcs



WALL

