











Before beginning assembly, separate all parts carefully. Please check all parts and all hardware against the diagram below before disposing of any packaging.

Do not use power tools to assemble, as they can cause reverse threading. Please assemble by hand. Power tools can be used once screws are mostly tightened, if needed.

For missing parts, please contact us via email: support@KingstonCasual.com

A	B	C	D	E	F	G
						
1X	6X	1X	6X	12X	18X	18X
H	I					
						
1X	1X					

1



2

