

Intelligent Tile Paver

Lift the handle and push the switch to the right to unlock



Hold the handle upward and lock it automatically

When unplugging the battery, first loosen the screw, and then tighten the screw after the battery is installed.

Name : Intelligent Tile Paver

Size: 335×135×120mm

Weight: 1.1kg

Vibration Frequency: 12000(r/min)

Voltage: Direct-current DC12V

USAGE

1. Place tiles in the designated position and place the machine on the tiles to be laid. Hold the control handle of the suction cup tightly, and the suction cup will hold the tile tightly.
2. Touch the micro-switch at the head on the left side of the machine by hand, and the machine starts to work. The protruding part of the ceramic tile shall be pasted flat in an instant.

Charging Instructions

1. After receiving this product, charge it first, and the power is not full when leaving the factory.
2. When charging, insert the power tail into the machine socket, then insert the plug into the power socket, and the charging display light will be on.
3. The normal charging time of this product is 3-4 hours, and it will stop itself when fully charged. The display light is green or off.
4. The product can work for more than 1.5 hours at most after full charge, but in order not to affect the service life of the product, please charge every day during normal use.
5. When the product is used normally, it needs to be charged once a day. If it is not used, it can be charged once a half month.

Attentions

1. No no-load operation is allowed for this machine.
2. The machine should be stored in a dry place to avoid touching liquid.
3. Remove the dust from the suction cup in time during the use.
4. It is strictly forbidden to disassemble the machine. The company will not be responsible for the results caused by self disassembly.

After-sale Service

1. The whole machine is warranted for three months.
2. If there is any problem with the machine after the warranty period, the maintenance fee is free, and only the cost of replacing parts is charged.
3. The company shall not be responsible for the damage caused by personal reasons or the loss caused by self disassembly and repair.
4. When there is a problem with the machine, please call the after-sales number in time.

Exchange Instructions

1. Exchange Instructions:

Exchange due to quality problems (return freight shall be borne by us) ; exchange not due to quality problems (return freight shall be borne by the buyer); quality problems are defined as damaged or incomplete goods.

For goods damaged in the process of logistics, our company is not responsible for the back and forth freight for the return and exchange of such goods. Please pay attention to check whether the package has opened traces, whether the outer package of the product is damaged or wet when signing for the goods.

If this happens, please don't sign for it. Please contact logistics or express for compensation.

2. Attention:

Our company is not responsible for the back and forth freight for the customers who pick up the goods on their own.

The second sale shall not be affected by the returned products.

Quality problems of the gifts, i.e. only the gifts have problems and do not affect the use of the main goods will not be returned.

If quality problems occur due to the abnormal use of users, they shall not be returned or replaced.

Tool Specialist Seiko Quality

Patent Product

Counterfeiting Must be Investigated