


VANITY CHAIR

Instruction Manual



Please read

- Do not discard any of the packaging until you are certain that you have all the necessary parts for the assembly.
- Please ensure that the packaging is disposed of in a safe and environmentally responsible way.
- During assembly, tighten screws by hand only. Once all screws are in place, you may tighten all screws completely.

Caution






- Never use this chair as a step ladder.
- Check that screws have not become loosened every 6 months. Retighten if necessary.
- Do not allow children to play with or operate the mechanism.
- Keep hands and feet clear of mechanism.
- Only the occupant should operate mechanism.



Usage Troubleshoot

- Adjust the height of the chair to suit your height. If it is not suitable for you, please contact us for help.
- If the chair is tilted to one side or forward, make sure the screws the seat plate are tightened, make sure the chassis is not upside down, and contact us if the problem cannot be resolved.
- If the fabric of the chair is torn or stained when you receive it, please contact us to get the replacement part or compensation.
- If the chassis is broken, please contact us for a replacement or or partial refund, please contact us for help.
- If part is missing, please contact us and provide the picture of the missing part, we will replace it.


Accessories List

A-Backrest ×1 		B-Seat Cushion ×1 	
		C-Rear Legs ×2 BACK 	D-Front Legs ×2 FRONT 
E-Screws×15 (M6x20mm) 	F-Shaped Allen Key 		

Step 1

Take out Backrest (A) and Seat Cushion (B).

Use 3 screws (M6×20mm) (E) to attach the Seat Cushion (B) to the Backrest (A) as shown.




Step 2

Take out the Front Legs (D).

Attach the Front Legs (D) to the bottom of the seat as shown.

Use Screws (E) to secure them tightly with the Allen Key (F).




Step 3

Take out the Rear Legs (C).

Attach the Rear Legs (C) to the bottom of the seat as shown.

Use Screws (E) to secure them tightly with the L-Shaped Allen Key (F).



Step 4

Adjust the Leveling Feet

Turn the adjustable feet at the bottom of the legs to keep the chair level and stable.

You can also use them to slightly adjust the height as needed.

