










Hi! Dear buyer, Thank you for choosing our products. Please carefully follow the assembly instructions below to ensure proper assembly and to avoid any potential issues.

Recommendations Before Beginning Assembly:

- 1. Read instructions, cover to cover**
- 2. Check that you have all the necessary tools listed in the instruction manual.**
- 3. Assemble on a clean non-marring surface.**
- 4. Have at least 2-3 adults on hand for assembly.**
- 5. Save all packaging until finished.**
- 6. Keep small parts and tools away from children.**

Assembly Notice:

- Lay out all the parts and hardware in an organized manner.
- Identify each part and match them with the corresponding labels in the manual.
- Assemble the product in the sequence specified to ensure stability.
- Do not overtighten screws during assembly as it may damage the parts or strip the threads.
- Double-check each step before proceeding to the next one.
- When you have completed assembly, we suggest you have more than one person to assist you with lifting and placing the product.

*** * What should you do when you encounter problems?**

Don't Worry—We'll Take Care of Everything!


If you encounter any difficulties (e.g., missing parts, damaged parts, unsuccessful assembly, etc.) during assembly, do not hesitate to contact the seller directly. The after-sales team will get back to you within 24 hours.

- If the product is damaged or missing any components, we are happy to provide replacement parts or a new product at no cost to you.
- To assist us in resolving your issue quickly, please contact our support team and provide clear photos of the damaged item or missing parts. This will help us identify the problem accurately and ensure a prompt solution. ✓✓


*** * Return Policy**

IMPORTANT NOTICE: Dear, If you encounter any issues with the product (quality-related or otherwise) that may require a refund or exchange, there is no need to initiate a return immediately. Please contact the seller directly, and in most cases, we can resolve the issue without requiring you to return the item. Thank you!


We hope these instructions help you successfully assemble the product. If you have any further questions or concerns, please feel free to contact the seller for assistance. Enjoy your new furniture!




Mounting Frame




1
x1




2
x1




3
x1




4
x1



5
x1



6
x1



7
x1



8
x1




9
x1



10
x1



11
x1




12
x7




13
x2




14
x1



15
x1



16
x7




17
x2




18
x1




19
x1




20
x1




21
x1




22
x1




23
x1



24
x1




25
x1




33
x1




34
x1




35
x2



36
x1



26
x1




27
x1



28
x2



29
x2




30
x1



31
x1



32
x1



37
x1

Installation part




A

x63(+2)
Ø6x35mm



B

x63(+2)
Ø15x10mm



C

x32(+2)
Ø6x30mm



D

x4



E

x2
M4x20mm




F

x16(+2)
Ø3x12mm




G

x45(+2)
Ø4x40mm




H

x1



I

x2




J

x2



K

x29




L(lift)

x1



M

x50(+2)
Ø3.5x14mm




N

x1



O

x1




P

x8(+1)



Q

x2
M4x14mm




R(right)

x1



S

x4



T

x1




U

x20(+1)
Ø4x15mm



V

x35(+2)
Ø3x14mm



W

x3



X

x4



Y

x20(+1)



CL

x2


L300mm



CR

x2


L300mm



DL

x2

L300mm




DR




x2

L300mm


1




CAM BOLT INSTALLATION AS BELOW:




Rotate connecting piece if found in the position illustrated above.




Correct orientation to receive bolts.




3




4




5




6




7




8




9




10




11




12




13




14




15




16




17




18




19



20



21




Door



D
x1




E
x1
M4x18mm




J
x2




M
x12
Ø3.5x14mm



22




23






NOTE : If you notice that the cabinet doors are not properly aligned, such as significant gaps or vertical or horizontal misalignment, please adhere to the following adjustment instructions.

1




lose these 2 screws

2




move hinge up/down

3




tighten these 2 screws again

1




lose this screw

2




shift hinge in/out

3




tighten this screw again

1



lose this screw would get hinge/door closer to side board

2



tighten this screw would get hinge/door away from side board

Drawer



A

x9
Ø6x35mm



B

x9
Ø15x10mm



D

x3



Q

x3
M4x14mm




F

x8
Ø3x12mm




G



x9
Ø4x40mm




DL
x2
L300mm




DR
x2
L300mm




24




25




26




27




28




29




30




31




32




33





34




35








38




39





42



43

