

ASSEMBLY INSTRUCTIONS

PRODUCT SPECIFICATION:

Input:AC100-240V
Output:DC24V/1.4A
Color Temperature:3000K
LED Max:25W (5×5W)
Light Switch:Touch dimmer

NOTE:

Before assembling your new lamp, please read the following precautions and instructions thoroughly.

IMPORTANT SAFETY INSTRUCTIONS

The electrical wire is connected continuously through the poles. Do not pull wires during unpacking, bad connections may result.

Place the lamp indoor dry area only.

1. Carefully unpack all parts from the packaging and place them on a flat/smooth surface. Be sure to remove all the packaging materials from the lamp.
*Do not plug into the electrical outlet when installing.
2. Unscrew the pre-installed **Screw(A)** and washer from the bottom of the pipe.
3. Screw the **Steel Pipe** onto the **Base** with the **Screw(A)** and the **Washer**.
4. Screw tightly the above steps with the **Allen Wrench**.
5. Connect the Male and female **Connector**.
6. Unscrew the pre-installed Screw(B) from the bottom of the Arch Pipe.
7. Insert the 5 **Arch Pipe** into the **Steel Pipe** and Secure it with the **Screw B**.
8. Connect the **adapter** and plug into the wall outlet, your lamp is ready to use.
9. Touch the **dimmer button** to adjust the brightness.

