

ASSEMBLY INSTRUCTIONS


V-WD26-1400

PF056




WARNING !





Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.


Make sure no parts are missing or damaged before assembly.


PACKAGE CONTENT

Board Identification

Not actual size









BOARD IDENTIFICATION


Not actual size




① x1




② x2




③ x2




④ x1




⑤ x1




⑥ x1




⑦ x1




⑧ x5




⑨ x5




⑩ x5




⑪ x5




⑫ x5




⑬ x4



⑭ x1




⑮ x1




⑯ x1

BOARD IDENTIFICATION

Not actual size




⑰ x1



⑱ x4




⑲ x1




⑳ x1

HARDWARE LIST




A	x57+1



Ø15x9.5

B	x57+1




Ø6x30

C	x42+1




Ø4x32

D	x27+1




Ø3.5x12

E	x60+2




Ø3x15

F	x8



G	x2




H	x1




Ø5x48


I	x4+1




CL	x5



CR	x5




DL	x5



DR	x5


Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.



STEP 1

PF056




Ø3.5x12	
E	x 30

CL	
CL	x 5

CR	
CR	x 5


STEP 2




A	
A	x 18


STEP 3


PF056






STEP 4









STEP 5

PF056






Ø6x30	
C	x 4

Ø15x9.5	
B	x 4

STEP 6





Ø6x30	
C	x 9


Ø15x9.5	
B	x 9


STEP 7

PF056











Use packaging material to lift and protect


STEP 8



STEP 9


PF056







A	x 14


STEP 10








Ø6x30	
C	x 6




Ø15x9.5	
B	x 4

STEP 11


PF056






Ø6x30		Ø15x9.5	
C	x 4	B	x 6

STEP 12







Ø6x30		Ø15x9.5	
C	x 6	B	x 4


STEP 13


PF056






STEP 14







STEP 15





STEP 16







STEP 17






STEP 18






STEP 19


PF056






STEP 20


PF056



G

STEP 21






G

STEP 22

PF056



bx2	ex2
G	

FURNITURE CARE AND MAINTENANCE

Medium - Density Fiberboard and Particle board

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



MAINTENANCE

· Tighten all bolts and screws again within the first 2 weeks of assembly
· Check the tightness of all bolts every 2 months, tighten them if necessary



CLEANING

· Clean the surface of the MDF (medium - density fiberboard) or PB (particle board) with a lightly dampened cloth.
· Small amount of mild soap can be used if necessary
- **Dry the surface immediately after cleaning.**

⚠ DO NOT use bleach or alcohol detergent to clean the surface.
⚠ DO NOT apply wood treatment on parts made with MDF and PB.
Medium - density fiberboard and Particle board will swell and distort when suffer from water damage.
Make sure to dry the furniture immediately after cleaning