


PARTS DIAGRAM



PARTS LIST

ITEM #	PART #	DESCRIPTION
1	UGP-BCD275215-01	Plastic Top cover
2	UGP-BCD275215-02	Screw M5x16
3	UGP-BCD275215-03	Upper hinge group
4	UGP-BCD275215-04	ceiling light group
5	UGP-BCD275215-05	Screw ST4.2x16
6	UGP-BCD275215-06	cover fixing base
7	UGP-BCD215-07	Cabinet
8	UGP-BCD275215-08	Adjustable foot
9	UGP-BCD275215-09	Lower hinge parts
10	UGP-BCD275215-10	Low adjustable foot1
11	UGP-BCD275215-11	Low adjustable foot2
12	UGP-BCD215-12	F evaporator
13	UGP-BCD215-13	left stop block
14	UGP-BCD215-14	Ornament strip for evaporator 1
15	UGP-BCD215-15	Ornament strip for evaporator 2
16	UGP-BCD275215-16	right stop block
17	UGP-BCD215-17	upper drawer
18	UGP-BCD215-18	bottom drawer
19	UGP-BCD275215-48	ice scoop
20	UGP-BCD275215-47	wine rack
21	UGP-BCD275215-25	Door switch
22	UGP-BCD275215-26	Middle hinge
23	UGP-BCD215-23	Screw ST4.2x10
24	UGP-BCD215-24	Glass Shelves
25	UGP-BCD215-25	Crisper drawer cover
27	UGP-BCD215-27	Chrome Trim for glass shelves
28	UGP-BCD215-28	Crisper drawer
29	UGP-BCD215-29	Upper door seal
30	UGP-BCD275215-35	Top Door Rack
31	UGP-BCD275215-36	Bottom Door Rack
32	UGP-BCD275215-37	Top hinge group
33	UGP-BCD275215-38	Chrome Trim for Door Racks
34	UGP-BCD215-34	Upper door
35	UGP-BCD275215175-40	fixed base for handle
36	UGP-BCD275215175-41	Handle
37	UGP-BCD275215175-42	screws M5*8
38	UGP-BCD275215175-43	screws M5*8
39	UGP-BCD275215-44	door stopper
40	UGP-BCD215-40	Bottom door seal
41	UGP-BCD215-41	Bottom door
42	UGP-BCD275215-54	process tube
43	UGP-BCD215-43	AC compressor
44	UGP-BCD275215-51	Screw M4X10
45	UGP-BCD275215-52	Flat Head Screw
46	UGP-BCD275215-53	Power supply cord with plug
47	UGP-BCD275215-54	Compressor base
48	UGP-BCD275215-55	back cover
49	UGP-BCD275215-56	Fixing Clamp for drying filter
50	UGP-BCD275215-57	Drier filter
51	UGP-BCD275215-58	Drip tray
52	UGP-BCD275215-23	Ice tray