


Congratulations on your purchase of our clock. Keep Perfect Time all day every day in style with our exquisite indoor and outdoor clocks.

Paddington Garden Clock Instructions

Set includes:



- 1x Wall Bracket (A)
- 1x Finial (B)
- 1x Twin Clock Section (C)
- 2x 20mm bolts & 5x nuts (D)
Nuts:
 - 1x 10mm
 - 2x 8mm x 2mm
 - 2x 8mm x 5mm
- 2x 22mm Screws and Plastic Wall Plugs (E)



Assembly Instructions

Please see photos below.

- 1.) Insert the 2 bolts (D) through the holes on either side of the finial bar and loosely secure with an 8mm x 5mm nut on each side. (pic.1)
- 2.) Open the twin clock section (C) and locate the threaded part of the finial bar and the two nut threads you put in during step 1. Tighten the 2x 8mm x 5mm nuts fully then fit the remaining 3 nuts (1 x 10mm and 2x 8mm x 2mm) (pic.2)
- 3.) Attach the finial (B) to the top of the bracket (pic.3)
- 4.) Open the clock casing and insert 1x AA battery into the back of each of the clocks. Using the setting wheel, turn the clock hands to the correct time. (pic.4)
- 5.) Attach the wall bracket in your desired location using the screws and fixings provided.



This product contains valuable materials which can be recovered or recycled – please dispose of in accordance with your local council directives

