



The Adirondack Chair

PARTS




$\frac{3}{4}$ " X 2 Adirondack Pin

FOLDED POSITION FOR STORAGE



REMOVE PINS
FOR FOLDING

DO NOT
REMOVE
SCREWS



MAKE SURE LOWER BACK SUPPORT
IS IN THE FORWARD POSITION
FOR UPRIGHT ASSEMBLY

INSERT PIN FOR ASSEMBLY, BOTH SIDES.
Rubber mallet or soft-faced hammer
may be needed to insert pins.

ASSEMBLY FOR UPRIGHT POSITION