






VOLLEYBALL REBOUNDER NET

Assembly Instruction Manual


⚠ WARNING

1. Always inspect before use and secure the base, replacing worn or damaged parts.
2. **Do Not** hang, climb, or strike the net or its framework.
3. Stay alert to ball rebounds and maintain a safe distance from the net.
4. For users aged 13 and above only. Not suitable for children under 13.
5. Disassemble and store the net in windy conditions to prevent tipping.
6. It is recommended to use with sandbags for a more secure fit.

ACCESSORIES LIST



INSTALLATION STEPS




STEP 1

Assemble the frame and brackets according to the pictures.

INSTALLATION STEPS

STEP 2


Use the lock pin (8) to adjust the frame to different angles.



8 X2

STEP 3



Use elastic buckles to fix the net to the frame. (Elastic buckle positions can be freely combined)



11 X30

STEP 4

Install anti-slip pads and ground anchors at the bottom of the support.



5 Levels Of Angle Adjustment

Question about your product? We are here to help.

Please Kindly Email : salesafterservice@outlook.com



10 X4



9 X4