



LED LIGHTED PARASOL

SAFETY & WARNINGS

- The ribs of the parasol might be compressed during transport. Please read the instruction manual carefully before opening the parasol to prevent permanent damage!
- Before opening the parasol, shake it slightly to drop the ribs on their natural open position.
- Turn the handle slowly to open the parasol easily.
- Gently turn the parasol upwards to fix it well as shown in Step 2.
- If you use the parasol in combination with a table, make sure the parasol is inserted in the middle hole of the table.
- If it is not use with any furniture, please fit suitable parasol stand, at least 40kgs or more.
- The parasol is only resistant to light rain and should not be used in heavy rain showers.
- Please close the parasol. Do not use in inclement weather. (strong winds, rain and snow.)

COMPONENTS



①: (x1)



②: (x1)




③: (x1)

INSTALLATION

Step 1

Push the supporting pole fully into the locking position with the spring clip as shown.



Step 2

Turn the handle clockwise to open the parasol. Have the parasol stand (not included) as support when in use, stand weight better more than 40kgs. Please buy the parasol stand/base separately.



Step 3

Press the red button to switch the LED lights on or off. The solar panel requires 6-7 hours to be fully recharged, and will last for 5 hours after full charged.



Step 4

Tilt usage function instruction:



Press the button
and tilt slightly.



Release the button
and tilt more.



The button will
automatically
spring back and
lock.



LED line.



Press the button
and tilt slightly.



Keep pressing
the button and
tilt.



Button will not
be able to spring
back.



LED line may be
broken causing
the item not to
light.

CLEANING & CARE

- Wipe clean with a wet cloth and a soft cleansing agent. Do not use any corrosive cleaning agent.
- The best way to keep the parasol in good condition is to store it in a dry place, out of reach of the elements, and cover the parasol when not in use.