



	<p>A 1pc</p>
	<p>B 1pc</p>
	<p>C 4 ps</p>
	<p>D 4ps</p>
	<p>E 1ps</p>

Warning

Read all instructions, precautions and warnings before assembly and use. It is the responsibility of the owner of this product to follow all instructions and assemble the product fully and safely as set out in this manual.

This product is suitable for home use only. Contact the retailer if any part of this product is missing or damaged so that replacement parts can be issued. Do not use any products until all missing parts are replaced.

- This product is suitable for home use only.
- Always read and follow all warnings and instructions provided
- You may need at least one person to help you with assembly
- You must use this product equipment on a solid, flat level surface.
- Do not use this product until it is properly assembled according to the instructions
- Do not exceed the weight limit: 140KG
- Always use the product as indicated. If you find any defective components whilst assembling or checking the parts, stop. Do not use the equipment until the problem has been rectified.