

















Assembly Instruction

LSF SOFA
RSF CHAISE


A Rsf-Seat Frame	B Lsf-Seat Frame	C Arm	D Panel-Rsf
 1 pc	 1 pc	 1 pc	 1 pc
E Short Panel	F Long Panel	G Cushion	H Cushion
 1 pc	 1 pc	 1 pc	 3 pcs
I Cushion	J Cushion	K Support	L Metal Leg
 1 pc	 1 pc	 1 pc	 8 pcs
M Allen Key 20 X 1-1/2 mm	N Bolt 6 X 1-4/5 mm	O Washer 1/4 X 4-1/2 mm	
 1 pc	 16 pcs	 16 pcs	




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

Legs and hardware are stored at the bottom of the 3 seater and chaise, please take out for assembly.


- 1** Align the metal leg (L) to the pre-drilled holes at the bottom of the rsf-seat frame (A), Isf-seat frame (B), insert bolts (N) and washers (O) then tighten with allen key (M). Rotate support (K) to tighten it.



- 2** Align and insert the arm (C) & long panel (F) to the Isf-seat frame (B), the short panel (E) & the panel-rsf (D) to the rsf-seat frame (A). Make sure all of back rest and arm rest had inserted to the bottom as picture showing.



- 3** Align all cushions (H), (J), (I) & (G) to the panel (D), (E) & (F), attach to the velcro, adjust and fix it properly.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.