

OVERVIEW


- Our clay blend and proprietary glaze come together to create the most durable kitchen sinks on the market. DeerValley kitchen sinks are guaranteed not to stain, chip, scratch or rust through regular use. But as with any sink, they require regular cleaning with warm, soapy water.

CARE & MAINTENANCE

- ✓ Rub lightly with a soft cloth on a regular basis and clean periodically by thoroughly rinsing with mild soap and warm water for additional preventative cleaning.
- ✓ Check regularly for cracks. To check for cracks, you can fill a basin with water and pour in colored paint to soak overnight. If there is a change in the water level, there may be cracks.
- ✓ If your sink develops any type of discoloration, using a mild abrasive, such as baking soda, will have your kitchen sink looking brand new again.
- ✓ Remove and clean the drains regularly to prevent stubborn stains.



RUB LIGHTLY
WITH SOFT CLOTH



CLEAN
PERIODICALLY



CLEAN SINK WITH
MILD ABRASIVE

NEVER

- X As with any surface that comes into contact with food, don't use harsh, abrasive cleaners or chemicals.
- X Avoid steel wool or metal cleaning pads on the sink.
- X Avoid leaving household cleaners or bleach in the sink for a long time, as they may ruin the finish of your sink.
- X Avoid dropping heavy or sharp objects from a height into the basin.
- X Avoid large friction with other ceramic surfaces during use, as it will abrade the glaze and cause breakage in appearance, affecting the overall decoration.
- X Avoid excessive temperature differences that may cause sink to break.



HARSH
CLEANERS



STEEL WOOL



BLEACH
STAYS ON TOO LONG

1 Year Warranty

All DeerValley kitchen sinks come with our Warranty within one year.



TEL: 312-626-9466 | support@deervalleybath.com