


Cleaning and maintenance:

1. Clean and maintain, turn off the power and unplug the power plug before cleaning.
2. When wiping and maintaining the heater, first cut off the power, wait for the product to cool down, and then wipe the outer surface with a damp soft cloth. The ventilation holes can be cleaned with a soft bristled brush.
3. The oil stains on the heater body must be cleaned thoroughly to prevent discoloration and damage.
4. After cleaning and maintenance, please pack each component into the packaging box according to the original packaging.
5. Store in a dry place and keep safe.
6. Cleaning and maintenance only require wiping with detergent and then wiping with a clean cloth.
7. Do not rinse directly with water.

Do not use chemical reagents such as diluents, toluene, acidic detergents, lamp oil, alcohol, etc. to wipe to avoid discoloration or deterioration.




## Dog House Heater manual



- Please carefully read this manual before use.
- The company reserves the right to interpret the instructions.
- The appearance of the product may vary from the actual product

Please install this dog house heater refer to A, punch on right place (try closer to the heater), and let the power cord through the hole or put the power cord to where your pets cannot reach, such as high place, the foot of wall etc, as shown in B. Prevent pets from biting the cord and keeping them safe.




Instructions for use:


1. Ensure that the pet heater is securely suspended.
2. Plug it in and turn on the power switch to warm it when the wind blows out.
3. Turn off the power switch and unplug it when you don't need to use the heater.

Maintenance:


- 1, make a screwdriver or other appropriate tools to remove the filter cover plate, take out the filter;
- 2, rinse the filter with tap water;
- 3, the filter screen dry water before loading the machine to use.




## Installation instructions:




A: First, use the screws provided in the accessory bag to secure the pegboard parallel to the pre-installed position of the equipment. It is recommended to install the pegboard at a height greater than the pet's height for optimal usage.




B: Choose the best position on the wall (near the end of the power cord) and drill a hole at least 39mm in diameter to ensure that the controller on the power cord can pass through this hole.



C: Guide the controller through the drilled hole and securely hang it in a suitable location. Please note that the controller has a waterproof rating of IP65, but it is advisable to avoid prolonged exposure to rain.  
NOTE: It is recommended to seal any excess gaps around the hole using sealing clay (not included, you will need to purchase it separately) or any other suitable material to prevent heat from escaping the dog house to the outside.



D: tilt the product down 45° and insert the buckle at the bottom of the fuselage bracket into the slot of the Hanging Board.



E: Hang the equipment securely according to the corresponding holes. The heating device can be used normally once the power is turned on.

## Warning:


To prevent potential dangers, please ensure that the heater is not covered by any objects during use. In order to provide you with better service, please carefully read this manual before using the product and store it properly for future maintenance. It is normal for the heater to emit a slight odor upon initial startup, which will dissipate within a few minutes. Please feel free to use it without any concerns.

### 1. Safety precautions

1. Use this Dog House Heater only with the specified voltage indicated on the heater's nameplate (120V~ 60Hz).
2. DO NOT modify the heater or cord, as it greatly increases the risk of fire and voids the warranty.
3. When installing, placing, and using the electric heater, DO NOT cover the air outlet and inlet. Keep flammable materials at least 1 meter away from the electric heater to prevent the risk of fire caused by overheating.
4. Please DO NOT place the electric heater close to other heat sources.
5. Please DO NOT use this electric heater near natural gas or gas pipelines, or near areas where paint or other flammable liquids are used or stored.
6. To prevent burns during or after using this heater, please avoid direct contact with your bare skin. If you need to move it, please ensure it is turned off and wait for the surface to cool down.
7. Please DO NOT cover the heater with clothing or any other objects.
8. Please DO NOT insert foreign objects or metal items into the air inlet or outlet of the dog house heater, as it may result in electric shock, fire, or damage to the heater.
9. Please DO NOT immerse the heater in water or allow water to enter the inside of the electric heater, as it may cause electric shock.
10. If the heater malfunctions, please contact us promptly or take it to a qualified service station.
11. Please DO NOT touch the electric heater with wet hands.
12. The most common cause of electric heater overheating is the buildup of dust or lint. Make sure to regularly clean the electric heater when it is not in use.

- 13.To prevent electric shock or fire, please DO NOT install electric heaters near windows with curtains.
- 14.Please DO NOT use frosted materials to clean the electric heater.instead, you can clean the heater with a cloth soaked in hot soapy water and wrung out. Before cleaning, ensure that the heater is powered off.
- 15.Please DO NOT turn on the power supply until the heater is fully installed and adjusted.
- 16.This dog house heater is not recommended for use in outdoor areas exposed to the elements or in humid environment.
- 17.Please DO NOT use near bathtubs, showers, swimming pools, or other liquids.
- 18.Please securel1 mount the electric heater on the wall or install it in the proper position, ensuring that the heater remains upright.
- 19.Please DO NOT wind up the power cord during use to avoid heat build-up in the power cord,which may cause danger.
- 20.Avoid using extension cords if possible. If you must use one due to a short power cord, make sure the extension cord has a higher power rating than the heater. Using a lower-rated extension cord may cause overheating and damage to the cord.
- 21.Please remember to turn off the power when the heater is not in use.
- 22.Please ensure that the power cord and fixed cables are kept away from the heater's hot surface.
- 23.Avoid wrapping or twisting the power cord, as this can weaken or damage the insulation. Also, ensure that the power cord is kept away from sharp objects.
- 24.DO NOT store the heater without allowing it to cool down first.
- 25.Please DO NOT install the electric heater directly under the electrical outlet.
- 26.To prevent the risk of electric shock or fire, make sure that the power cord and electric heater are not exposed or immersed in rain or any other liquid.
- 27.Please use the heater in accordance with these instructions. To avoid causing fire electric shock or injury, DO NOT use other manufacturer's product instructions for use with this dog house heater.







**Product Introduction:**  
This product uses advanced PTC semiconductor ceramic heating elements, which have high thermal efficiency, fast and uniform heating, no oxygen consumption, safety and reliability, long-term use will not cause stuffiness, and have multiple safety designs, overheating protection, low noise, long service life, and can switch gears according to needs.



**Product specifications:**

Power:	600W
Voltage:	120V~60Hz

**Product List:**

		
Heater	Controller	Hanging board
		
Screws	Safety bolt	instructions