

ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Screwdriver
(Not included)



(included)
Allen Wrench



2 - People

ASSEMBLY RATING



EASY ——→ DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 20-06-05

CHECK BEFORE STARTING

- [ ] Are you missing anything?

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] Should we send any replacements?

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] Check out our Quick Tips!

  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] Prep Time!

  Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


GLASS CABINET






PARTS

#1 1pc



Sideboard

#2 4pcs



Legs

HARDWARE

#A 8pcs



Ø5/16" x 2-3/8"

#B 8pcs



Spring washer Ø5/16"

#C 8pcs



Flat washer Ø5/16" x 3/4"

#D 1pc




Allen key 4mm

#E 1pc



Tipping Restraint

Exploded View



ASSEMBLY INSTRUCTIONS

1

Align Legs (#2) to the Sideboard (#1), then secure by using bolts (#A) with washers (#B,#C) and Allen key (#D) .

Part (#1) x1pc


Part (#2) x4pcs

Hardware (#A) x8pcs

Hardware (#B) x8pcs

Hardware (#C) x8pcs

Hardware (#D) x1pc




ASSEMBLY INSTRUCTIONS

2

Part (#1) x1pc

Hardware (#E) x1pc



ASSEMBLY COMPLTED

Please ensure the fumiture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolis and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

This prodict is intended for RESIDENTIAL USE ONLY and not for commercial use