


ASSEMBLY INSTRUCTION

A Table Top




1pc

B Leg



2pcs

C Side Rail




2pcs

D Middle Rail



1pc

E Reinforcing Bar



1pc

F Bolt
Ø5/16"x1-1/2"



8pcs

G Bolt
Ø5/16"x2"



4pcs

H Flat Washer
Ø5/16"x22mm



12pcs

I Lock Washer
Ø5/16"x13mm



12pcs

J Allen Key
M5



1pc

K Bolt
Ø5/16"x3-3/4"



2pcs

L Half Moon Nut
Ø5/16"




2pcs

M Hex Nut
Ø5/16"x1/2"x6mm



2pcs

N Spanner
Ø5/16"



1pc

O Bolt
Ø1/4"x2-1/4"



4pcs

P Flat Washer
Ø1/4"x19mm



4pcs

Q Lock Washer
Ø1/4"x11mm




4pcs

R Allen Key
M4




1pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1** Assembling Middle Rail (D) to Leg (B), rotate Bolt (K) to Leg (B) Firstly, then attach Middle Rail (D) to Leg (B) through Bolt (K). Next using Half Moon Nut (L) and Hex Nut (M) to lock with Bolt (K) by Spanner (N) as below shown.



- 2** Attach the Side Rail (C) to the Middle Rail (D) & Leg (B) using Bolt (G), Lock Washer (I) & Flat Washer (H) by Allen Key (J) as below shown.



- 3** Attach pre-assembled Leg (B) to Table Top (A) using Bolt (F), Flat Washer (H) & Lock Washer (I) by Allen Key (J) as below shown. Then attach Reinforcing Bar (E) to Table Top (A) using Bolt (O), Flat Washer (P) & Lock Washer (Q) by Allen Key (R) as below shown.




Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.


ASSEMBLY INSTRUCTION

A Chair Body




1pc

B Cushion



1pc

C Pillow




1pc

D Front Leg




2pcs

E Left Back Leg



1pc

F Right Back Leg



1pc

G Lock Washer
Ø5/16"x13mm



8pcs

H Flat Washer
Ø5/16"x19mm



8pcs

I Bolt
Ø5/16"x2-1/2"




8pcs

J Allen Key
M5




1pc



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1 Put the Chair Body (A) on a smooth flat surface, attach Front Leg (D) to the Chair Body (A) using Bolt (I), Lock Washer (G) and Flat Washer (H) on both holes of Chair Body (A) by Allen Key (J). Turn the Allen Key (J) in Bolt (I). But not too tight.



Take the Allen Key, and turn the bolts until the legs are secure. **DO NOT TIGHTEN COMPLETELY.** Stop when you feel you are adding force to tighten the bolt.

- 2** Then attach the Left Back Leg (E) & Right Back Leg (F) to the Chair Body (A) using Bolt (I), Lock Washer (G), Flat Washer (H) in both holes of Left Back Leg (E) & Right Back Leg (F) and Chair Body (A). Turn the Allen Key (J) in Bolt (I).

Stand chair up on an even surface and check that it is balanced. If there is a slight wobble, apply downward pressure in the corner where a leg is uneven. Keeping pressure in that corner, tighten all bolts. If balanced, apply downward pressure evenly in the center and tighten all bolts. Do not over-tighten beyond hole depth.



Helpful Tip:
-Instead of applying downward pressure while reaching under to tighten bolts, have someone sit in the chair while you tighten the bolts.

Turn left or turn right to adjust the leveler until the chair is stabilized.

Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.