


Assembly Instructions

Console Table






Contact Us

We're here to help you.

Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.


Warm Tips

1. Carefully read these instructions and keep them for future reference.
2. Check the parts list and confirm everything's there before starting assembly.
3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.





We recommend using hand tools for assembly.

If an electric screwdriver is used, reduce power and torque to avoid damage to the product.




Install the Anti-Tip Straps

Using the anti-tip straps can reduce the risk of tipping over, but can not eliminate it.















Assembly Instructions













Caution

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.

Parts List


1  1pc	2  1pc	3  1pc	4  2 pcs
5  2 pcs	6  2 pcs	7  4 pcs	8  1pc
9  2 pcs	10  2 pcs	11  2 pcs	12  4 pcs

Hardware List


A	B	C	D	E	F	G
 M6x40mm 56 pcs	 Ø15x12mm 56 pcs	 Ø7.8x30mm 19 pcs	 M4x65 1pc	 Ø7x47mm 5 pcs	 2 pcs	 M6x30mm 4 pcs
H	I	J	K	L	M	
 M8x70mm 4 pcs	 M8x10x5mm 4 pcs	 M8 1pc	 Ø17x1.5mm 4 pcs	 Ø14x4mm 9 pcs	 37mm pc	

Installation of Cams and Pins


Step 1-2: Align the plastic part with the mounting hole and press it in. If you can't press it in, loosen the screw counter clockwise or completely remove the screw from the plastic part and try again.
Step 3-4: After pressing the plastic part into place, use a screwdriver to tighten the screw clockwise.



Screw the pin into the hole. Set the cams correctly by aligning the head of the cams with the lock pins. Lock the cam by turning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.




1




A	C	H
		
M6x40mm	M7.8x30mm	M8x70mm
4 pcs	2 pcs	4 pcs

x2

2




x4



x2


A

M6x40mm
16 pcs





3

E	D
	
Ø7*47mm	M4*65
2 pcs	1 pc




4

B	M
	
Ø15*12mm	37mm
8 pcs	1 pc



5


B	C
	
Ø15*12mm	M7.8x30mm
8 pcs	4 pcs




6

A

M6x40mm
4 pcs




7




A

M6x40mm
4 pcs


8




B	G	I	J
			
Ø15*12mm	M8x30mm	M8x14mm	M8
4 pcs	4 pcs	4 pcs	1 pc
K			
			
Ø17x1.5mm			
4 pcs			




9



E	D
	
Ø7*47mm	M4*65
4 pcs	1 pc
B	
	
Ø15*12mm	
4 pcs	




10




B


Ø15*12mm
4 pcs

11



A

M6x40mm
8 pcs


12




B	L
	
Ø15*12mm	Ø14*4mm
8 pcs	8 pcs


 Caution! Tap lightly

13




A

M6x40mm
19 pcs

14



B	C
	
Ø15*12mm	M7.8x30mm
19 pcs	12 pcs

Rotate 180°




15

F


2 pcs

Step1



Wall



Step2



Step3



Thank you for your support!

