
Armless Chair
Assembly Manual



FSC
www.fsc.org
100%
Wood from well-managed forests
FSC® C183324





⚠ CAUTION THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Parts


Armless Chair with Fold-Down Middle Back

A  Back	B  Seat


or Regular Chair Armless

A  Back	B  Seat

Step 1: Slide the Back (A) into the metallic quick connectors of the Seat (B). Push down the Back (A) firmly until each side is locked into place and an audible “click” is heard.




Step 2: Attach the back cover to the bottom of the Seat (B) with Velcro.




How to Use Fold-Down Middle Back


Step 1: As shown in the figure, connect the cable (C) into the cable (D).



Step 2: Connect the power cord (E) of the power outlet to the power outlet.




Step 3: Flip the headrest upward and fold the backrest section downward to activate its full functionality.You can find thereading light and power outlet on it.




How to Connect


Step 1: Lift the side of the sofa with the protruding side brackets, insert it into the side slots on the opposite side, to lock them into place.




Step 2: Connect one end of the power cord into the DC adaptor located at the bottom of the arm. Plug the other end of power cord into the power outlet.


Note: After all the connections are made, the green LED will be lit up.







Wireless Phone Charger
Power: 10W



How to operate