

Assembly Instructions

Caution: You must read these Assembly Instructions before you proceed

Care & Maintenance



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.



- Children should not climb or jump on the furniture.



- Do not write on furniture without a padded barrier to protect the surface.



- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine.
Whenever possible cover the product and /or place under patio or awnings.



- Not for commercial use. For residential use only.




- Stains may be removed with mild soap solution and damp cloth.



- Dust and pick-up spills using a clean, non-colored, lint- free cloth.








Please look into the **Seat Panel** for hardware packs.

Swivel Club Chair





Caution: This Swivel Club Chair is NOT a TOY.
Keep your child / children at bay during the assembly process.
Whenever lifting or moving the Swivel Club Chair and to prevent any damage to it, two adults may be needed to execute these actions.

Part List

Label	Picture	Description	Qty
A		Left Leg Panel	1
B		Right Leg Panel	1
C		Backrest Panel	1
D		Seat Panel	1
E		Support Seat Panel 1	1
F		Support Seat Panel 2	1
G		Support Seat Panel 3	2
H		Support Bar	1
I		Swivel base	1

Part List


Label	Picture	Description	Qty
J		Seat Cushion	1
K		Back Cushion	1

Hardware


No.	Picture	Description	Qty
①		Screw (M6x35mm)	3
②		Screw (M6x60mm)	3
③		Screw (M7x70mm)	5
④		Screw (M7x90mm)	5
⑤		Bolt (M6x20mm)	5
⑥		Bolt (M6x40mm)	5
⑦		Levellers	6
⑧		Washer Iron (Ø6xØ20x2mm)	5
⑨		Wood Button	5
⑩		Allen Wrench	2

Assembly Preparation

Before Beginning Assembly:




Ax1




Bx1




Cx1



Dx1



Ex1



Fx1




Gx1




Hx1



Ix1



Jx1



Kx1

- | | | |
|---|--|----|
| ① | | x3 |
| ② | | x3 |
| ③ | | x5 |
| ④ | | x5 |
| ⑤ | | x5 |
| ⑥ | | x5 |
| ⑦ | | x6 |
| ⑧ | | x5 |
| ⑨ | | x5 |
| ⑩ | | x2 |



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Swivel Club Chair has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the Swivel Club Chair, the above picture to assemble to help you put the various parts into perspective. Please read through the instructions here below to familiarise the parts and steps before assembly.

Step 1




Unpack and place all parts on a clean, non-marring surface.

Step 2



With assistance from your adult partner, attach the Support Seat Panel 1 (E) to the Support Seat Panel 2 (F) using Support Seat Panel 3 (G) and Screw (③) with Allen Wrench (⑩) as shown above.


Step 3



With assistance from your adult partner, attach the Backrest Panel (C) to the Left Leg Panel (A) using Bolts (⑥) with Allen Wrench (⑩) as shown above.


Do not fully tighten the Bolts.

Step 4



With assistance from your adult partner, attach the Support Seat Panel 1 (E), Support Seat Panel 2 (F), Support Seat Panel 3 (G), Support Bar (H) as shown above.


Step 5



With assistance from your adult partner, attach the Right Leg Panel (B) to the Backrest Panel (C) to the using Bolts (⑥) with Allen Wrench (⑩) as shown above


Do not fully tighten the Bolts.

Step 6



Attach the using Screws (④) with Allen Wrench (⑩) as shown above.
Do not fully tighten the Screws.

Step 7




With assistance from your adult partner

7.1 Attach the Seat Panel (D) to the Swivel Club Chair, flip Swivel Club Chair using Screws (②) with Allen Wrench (⑩) as shown above.

7.2 Attach the Seat Panel (D) to the Swivel Club Chair, flip Swivel Club Chair using Screws (①) with Allen Wrench (⑩) as shown above.


Do not fully tighten the Screws.

Step 8



Attach the Levellers (⑦) in to Swivel base (I)


Step 9



Upside down Swivel Club Chair and Swivel base (I) as shown in the image.
With assistance from your adult, attach the Swivel base (I) to the Support Seat Panel (E), (F) using Bolts (⑤) and Washer Iron (⑧) with Allen Wrench (⑩) as shown above.

Do not fully tighten the Bolts.

Step 10



Inspect the Swivel Club Chair and make sure all parts are adequately connected.

Then EXERT pressure, floorwards onto the Swivel Club Chair with both hand.

This pressure will help align all parts at all joints.

In a sequential manner, tighten all Bolts and Screws at all joints.


CAUTION: When tightening these screws and bolts, tighten sequentially.

DO NOT tighten any screw or bolt fully and then move towards the next one. This could cause the frame to warp.

WARNING!! IF THE SWIVEL CLUB CHAIR SEATE IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.

Attach the Wood Button (9) into the Swivel Club Chair as shown in picture above.

Step 11



Place the Seat Cushion (J), then the Back Cushions (K) onto the Swivel Club Chair.

Then affix the "magic tape straps" around the Chair as shown above.

Your Swivel Club Chair is ready to be used.

This Swivel Club Chair can only be used on a flat, level surface.